



UNIVERSAL MEDIA REMOTE

多功能媒體遙控器
유니버설 미디어 리모컨



0211 Part No. X17-47707-01
Printed in China

Xbox 360 Universal Media Remote

INTRODUCTION

Thanks for choosing the Xbox 360 Universal Media Remote for the Xbox 360® video game and entertainment system. Your remote lets you control your TV and Xbox 360 DVD and CD playback, Windows Media Centre-based technology, and the Xbox Dashboard with one slick, stylish remote. The Universal Media Remote features:

- Ergonomic design with backlit buttons.
- Extensive and easy to use code library.
- Integrated Microsoft Windows Media Centre controls.
- The Xbox Guide button and A, B, X, and Y buttons for easy access to the Xbox Dashboard.

To enhance your wireless experience, consider adding an Xbox 360 Wireless Networking Adapter and Xbox 360 Wireless Controller. For a superior media experience with high-definition TVs, check out the full line of Xbox 360 AV cables for the one that takes maximum advantage of your AV setup.



WARNING

Before using this product, read this manual and the Xbox 360 console manuals for important safety and health information. Keep all manuals for future reference. For replacement manuals, visit www.xbox.com/support.

The limited warranty covering this product is contained in the Xbox 360 console manual and is available online at www.xbox.com/support.



Disposable Battery Safety

Improper use of batteries may result in battery fluid leakage, overheating or explosion. Released battery fluid is corrosive and may be toxic. It can cause skin and eye burns, and is harmful if swallowed. To reduce the risk of injury:

- Keep batteries out of reach of children.
- Do not heat, open, puncture, mutilate, or dispose of batteries in fire.
- Do not mix new and old batteries or batteries of different types (for example, carbon-zinc and alkaline batteries).
- Remove batteries if they are worn out or before putting away for an extended period of time.
- If a battery leaks, remove all batteries, taking care to keep the leaked fluid from touching your skin or clothes. If fluid from the battery comes in contact with skin or clothes, immediately wash the skin with water. Before inserting new batteries, thoroughly clean the battery compartment with a damp paper towel, or follow the battery manufacturer's cleaning recommendations.
- Dispose of old, depleted, or leaking batteries in accordance with the battery manufacturer's instructions and local and national disposal regulations.

Insert batteries in accordance with the following instructions.

SET-UP YOUR UNIVERSAL MEDIA REMOTE

Insert Batteries

To insert batteries into the remote control:

- 1 Remove the remote battery cover.
- 2 Insert two new AA (LR6) batteries as shown on the underside of the remote battery cover. For best performance, AA rechargeable batteries are not recommended.
- 3 Replace the remote battery cover.

Programme the Universal Media Remote for Your TV

Before your remote can work with your TV, you need to programme it for use with your particular brand of TV. There are two ways of programming your remote: manually entering your TV code or scanning to find your TV code.

The code list at the end of this manual covers many popular TVs. For the latest list of TV library codes, go to www.xbox.com/support.

NOTE

After 30 seconds of inactivity, the remote will exit the screen. Pressing any button other than 0-9 or CH/PG returns the remote to its original settings.

To enter a TV code:

- 1 Turn on your TV and point the remote towards it.
- 2 Press and hold the TV and OK buttons simultaneously for two seconds. All of the buttons on the media remote will then light up for two seconds, after which only the numeric TV buttons (1-12) will stay on.
- 3 Enter the code for your TV.
- 4 Press the TV button again to save the code and exit. All of the buttons on the remote will blink three times to confirm your selection.

To scan for a TV code:

- 1 Turn on your TV and point the remote towards it.
- 2 Press and hold the TV and OK buttons simultaneously for two seconds. All of the buttons on the remote will then light for two seconds, after which only the numeric TV buttons (1-12) will remain lit.
- 3 Press the CH/PG button to send a series of off commands to your TV. Repeat until the TV turns off.

NOTE

Give your TV enough time to respond to the off command after each button press. Some TVs take more time to react to off commands than others.

- 4 Press the TV button to save the code and exit. All buttons on the remote will blink three times to confirm the code.

NOTE

If, after setting the TV code, you find that the remote is not functional or has incomplete or inaccurate functionality, try a different code for your TV manufacturer or scan for another code. To scan for another code after the TV turns off in step 3, turn on the TV then continue to press CH/PG for other codes prior to proceeding to step 4.

The Xbox 360 Universal Media Remote works only with TVs and the Xbox 360 console. It does not control VCRs, DVRs, DVD players, or audio equipment.



USING THE UNIVERSAL MEDIA REMOTE

Your remote operates like any TV remote. It also includes controls for your Xbox 360 console and a button that gives you immediate access to a connected PC with Windows Media Centre-based technology.

Controller Buttons

Your remote is equipped with the Xbox Guide button and the A, B, X and Y buttons. You can use these, along with the OK button, to move around and control the Xbox Guide and the Xbox Dashboard on your Xbox 360 console, just as you would with your controller.

Windows Media Centre Start Button

The Windows Media Centre Start button lets you access a Windows Media Centre-based PC through your Xbox 360 console. If you are set up to use Windows Media Centre on your Xbox 360 console, pressing the button will take you to the Media area of the Xbox Dashboard.

If you are not yet set up to use Windows Media Centre on your console, pressing the button will start the Windows Media Centre set-up wizard.

The Windows Media Centre button will also turn on the console if it is off.

CLEAN YOUR REMOTE

Clean only with a dry or slightly damp cloth. Using cleaning solutions or attempting to clean connectors may damage your remote.

TROUBLESHOOTING

If you encounter problems, try the possible solutions indicated below.

DVD Features Don't Work

Some DVDs may not support all of the Xbox 360 DVD playback features, such as subtitles, multilingual audio tracks, multiple viewing angles and slow-motion play. For more information on supported features, see the DVD producer's documentation. In rare instances, certain DVDs may not operate properly. This is primarily due to variations in the manufacturing process or the software encoding of the DVD video software.

Video or Sound Is Poor or Not Working

Make sure your AV cable is properly connected. For setup and AV troubleshooting information, see the Xbox 360 Setup manual or your AV cable instructions.

Buttons Don't Work

The batteries are still fresh by testing the remote with new batteries. Try removing the batteries from the remote, pressing all buttons twice, and then replacing the batteries.

If individual buttons don't work, follow the instructions for cleaning your remote.

Poor Performance with the Xbox 360 Console

- Make sure that your remote is fully charged.
- Point the remote directly at the console.
- Check for interference from other devices that transmit or receive radio signals.
- Make sure that you're using the remote within 30 feet of the console.
- Close drapes and blinds during daylight hours to minimise ambient infrared.

IF YOU NEED MORE HELP

For answers to common questions, troubleshooting steps, and Xbox Customer Support contact information, visit www.xbox.com/support.

Do not take your Xbox 360 console or its accessories to your retailer for repair. Please visit www.xbox.com/support for troubleshooting and service information.



Do Not Attempt Repairs

Do not attempt to take apart, service or modify the Xbox 360 console, power supply or its accessories in any way. Doing so could present the risk of serious injury or death from electric shock or fire, and for safety reasons it will void your warranty.

DISPOSAL OF WASTE BATTERIES AND ELECTRICAL & ELECTRONIC EQUIPMENT



This symbol on the product or its batteries or its packaging means that this product and any batteries it contains must not be disposed of with your household waste. Instead, it is your responsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. For more information about where to drop off your batteries and electrical and electronic waste, please contact your local city/municipality office, your household waste disposal service, or the shop where you purchased this product.

This product contains alkaline batteries.

This product is for use with NRTL-listed (UL, CSA, ETL, etc.) and/or IEC/EN 60950 compliant (CE marked) Information Technology equipment.



Waste batteries, please recycle.

FOR CUSTOMERS IN TAIWAN

Product Information
Product name: Xbox 360 Universal Media Remote
Model no.: Universal Media Remote
Designated voltage: 3 VDC
Country of origin: China
Manufacturer name: Microsoft Corporation
Importer name: Synnex Technology International
Importer's Address: 4th Fl. 75, Section 3, Min-Sheng E. Rd., Taipei 104
Importer's number: (02) 2506-3320

COPYRIGHT

Information in this document, including URL and other Internet Web site references, is subject to change without notice. Unless otherwise noted, the example companies, organisations, products, domain names, e-mail addresses, logos, people, places and events depicted herein are fictitious, and no association with any real company, organisation, product, domain name, e-mail address, logo, person, place or event is intended or should be inferred. Copying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the express written permission of Microsoft Corporation.

Microsoft may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from Microsoft, the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property.

© 2011 Microsoft Corporation. All rights reserved.

Microsoft, Windows, Windows Media, Xbox, Xbox 360, Xbox LIVE, the Xbox logos, and the Xbox LIVE logo are trademarks of the Microsoft group of companies.

Xbox 360 多功能媒體遙控器

簡介

感謝您為 Xbox 360® 視訊遊戲家庭娛樂系統購買 Xbox 360 多功能媒體遙控器。流線外型兼具時尚感的遙控器可以讓您控制電視和 Xbox 360 DVD/CD 的播放、Windows Media Centre 和 Xbox 設定畫面。多功能媒體遙控器功能：

- 具有背光按鍵的人體工學設計。
- 龐大且容易使用的程式碼資料庫。
- 已與 Microsoft® Windows® Media Center 控制功能整合。
- 具有 Xbox 360 按鍵以及 A、B、X、Y 按鍵，讓您更容易存取 Xbox 設定畫面。

若要進一步享受無線的便利，可以考慮另行購買 Xbox 360 無線網路卡與 Xbox 360 無線控制裝置。若要透過高畫質電視欣賞絕佳的畫面，請參考全系列的 Xbox 360 AV 端子線，讓您的 AV 設定更加完善。



警告

在使用此產品前，請閱讀本手冊與 Xbox 360 手冊，以取得重要的安全 and 健康資訊。請妥善保存所有手冊，以供未來參考之用。如需更換手冊，請至 www.xbox.com/support。

涵蓋此產品的有限瑕疵責任擔保在 Xbox 360 主機手冊當中，您同時也可在 www.xbox.com/support 找到線上的版本。



拋棄式電池的安全

電池使用不當可能會導致電池液體外洩、過熱或爆炸。外洩的電池液具有腐蝕性而且可能具有毒性。若其接觸到皮膚與眼睛將會導致灼傷，如果吞嚥也會導致傷害。若要降低傷害的風險：

- 請將電池放置於孩童拿不到的地方。
- 請勿加熱、開啟、穿刺、拆解或將電池置於火中。
- 請勿將新舊電池或不同類型（例如碳鋅或鹼性）電池混合使用。
- 如果電池已耗損或長時間不使用裝置，請將電池取出。
- 若電池的電解液漏出，請立即將電池取出，並避免您的皮膚或衣物接觸到外洩的電解液。若皮膚或衣服接觸到電池的化學液體，請立即用清水加以沖洗。在放入新電池之前，請用濕紙巾或者依照電池製造廠商建議的方式，將電池槽確實清理乾淨。
- 請依照電池製造商的指示以及當地與全國廢棄物處理規定（如果適用）加以回收或處理老舊、耗盡或外洩的電池。

依照下列指示放入電池。



廢電池請回收

設定您的多功能媒體遙控器

放入電池

如何將電池放入控制器：

1. 將媒體遙控器的電池外殼打開。
2. 按照媒體遙控器電池外殼內側所示，將兩個新的 AA (LR6) 電池放入。若要獲得最佳效能，不建議使用 AA 可充式電池。
3. 蓋上遙控器電池外殼。

為您的電視設定多功能媒體遙控器

在開始使用遙控器之前，您必須先針對電視的品牌來設定遙控器。設定遙控器的方式有兩種：手動輸入電視代碼或自動搜尋電視代碼。

若要取得最新的電視代碼資料庫，請至 www.xbox.com/support。

注意

如果您停止使用控制器 30 秒，控制器便會自動離開電視設定模式。按下除了 0 - 9 或 CH/PG 以外的任何按鍵都會讓遙控器回復原來的設定。

如何輸入電視代碼：

1. 開啟您的電視並將遙控器對準它。
2. 同時按住 [TV] 和 [OK] 鍵兩秒鐘。媒體控制器上的所有按鍵會閃光兩秒鐘，之後則只有數字 TV 鍵 (1-12) 亮著。
3. 輸入您電視的代碼。
4. 再次按下 [TV] 鍵儲存代碼並結束。遙控器上的所有按鍵會閃三次，以確認您的選擇。

如何掃描電視代碼：

1. 開啟您的電視並將遙控器對準它。
2. 同時按住 [TV] 和 [OK] 鍵兩秒鐘。控制器上的所有按鍵會閃光兩秒鐘，之後則只有數字 TV 鍵 (1-12) 亮著。
3. 按下 CH/PG 鍵傳送一系列的關閉指令給您的電視。重複動作直到電視關閉。

注意

請提供足夠的時間讓電視回應每次按鍵按下的關閉指令。某些電視會比其他需要更多的時間來反應關閉指令。

4. 按下 [TV] 鍵儲存代碼並結束。遙控器上的所有按鍵會閃三次，以確認程式碼。

注意

如果您在設定電視代碼後，發現遙控器沒有作用，或是功能不完全或不正確，請輸入您電視製造商的其他電視代碼，或是掃描其他代碼。如要在執行步驟 3 關閉電視後掃描其他代碼，請開啟電視並持續按下 CH/PG 來尋找其他代碼，然後進行步驟 4。

Xbox 360 多功能媒體遙控器只適用於電視和 Xbox 360 主機。它無法控制 VCR、DVR、DVD 播放器或音效設備。

使用多功能媒體遙控器

多功能媒體遙控器的運作和任何電視遙控器相同。它同時可控制 Xbox 360 主機，還提供一個按鍵讓您能立即存取所連接的 Windows Media Center 個人電腦。

控制器的按鍵

您的遙控器配有 Xbox 360 按鍵及 A、B、X、Y 按鍵。您可以使用這些按鍵以及 [OK] 鍵來轉換控制 Xbox 360 主機上的 [Xbox 快顯功能表] 和 [Xbox 設定畫面]，就跟其他一般控制器相同。

Windows Media Center 開始鍵

Windows Media Center 的 [開始] 按鍵可讓您透過 Xbox 360 的主機來存取安裝有 Windows Media Center 的個人電腦。如果您的設定是在 Xbox 360 主機上使用 Windows Media Center，則按下此按鍵會帶您到 Xbox 設定畫面的 [媒體] 區。如果尚未設定在您的主機上使用 Windows Media Center，則按下此按鍵會啟動 [Windows Media Center 安裝精靈]。

如果主機是關閉的，Windows Media Center 開始鍵也能啟動主機。

清理您的遙控器

僅可使用乾布或微濕的布清理。使用清潔劑或試圖清理接頭有可能會損壞您的遙控器。

疑難排解

如果您遇到了問題，請嘗試以下所提供的解決方案。

DVD 功能沒有作用

有些 DVD 可能不支援所有的 Xbox 360 DVD 播放功能，例如字幕、多國語音、多角度檢視和慢動作播放。如需所支援功能的詳細資訊，請參閱 DVD 產品的說明手冊。比較罕見的狀況是，某些 DVD 可能不會正常運作。這主要是因為生產製作過程中的差異，或者是 DVD 視訊軟體編碼不同的關係。

視訊及聲音效果不佳或無法輸出

確認您的 AV 端子線有正確連接。如需設定與 AV 疑難排解的詳細資訊，請參閱 Xbox 360 安裝手冊或是您的 AV 端子線說明指示。

按鍵沒有作用

請確認您的遙控器有充足的電源。如果遙控器上有紅燈閃爍，請更換電池。

如果某顆按鍵沒有作用，請依照指示清潔您的遙控器。

搭配 Xbox 360 主機使用的效果不佳

- 請確認遙控器有充足的電源。
- 請將遙控器對準主機來使用。
- 請查看附近有無其他也會發射或接收無線電訊號的裝置在干擾遙控器。
- 請確認您在離主機 9 公尺 (30 英尺) 的範圍內使用遙控器。
- 白天時請關上窗簾或百葉窗，以減少環境中的紅外線干擾。

Xbox 360 유니버설 미디어 리모컨

소개

Xbox 360® 비디오 게임 및 엔터테인먼트 시스템용 Xbox 360 유니버설 미디어 리모컨을 구입해 주셔서 감사합니다. 멋지고 세련된 이 리모컨 하나만 있으면 TV, Xbox 360 DVD 및 CD 재생, Windows Media Center 기반의 PC 및 Xbox 대시보드를 모두 제어할 수 있습니다. 유니버설 미디어 리모컨의 기능은 다음과 같습니다.

- 단추에 백라이트를 채용하는 등 인체 공학적 디자인을 적용하였습니다.
- 광범위하고 쉽게 사용할 수 있는 코드 라이브러리가 있습니다.
- Microsoft Windows Media Center를 제어할 수 있습니다.
- Xbox 가이드 단추와 A, B, X 및 Y 단추를 사용하여 Xbox 대시보드에 편리하게 접근할 수 있습니다.

보다 나은 무선 환경을 구축하려면 Xbox 360 무선 네트워크 어댑터 및 Xbox 360 무선 컨트롤러를 사용하십시오(별도 구입). 고화질(HD) TV를 통한 뛰어난 멀티 미디어 환경을 원하는 경우에는 여러분의 AV 시스템을 최대로 활용할 수 있는 Xbox 360 AV 케이블을 사용해 보십시오.

⚠ 경고
제품을 사용하기 전에 이 설명서 및 Xbox 360 제품 설명서에 명시된 안전을 위한 주의 사항을 읽으십시오. 모든 설명서는 나중에 참고할 수 있도록 보관하십시오. 설명서를 분실한 경우 www.xbox.com/support 에 방문하십시오.

이 제품에 관련된 제한적 보증은 Xbox 360 본체 설명서에 있으며, www.xbox.com/support 에서도 온라인으로 확인할 수 있습니다.

⚠ 배터리 안전성
배터리를 잘못 사용하면 배터리 액이 누수되거나 과열 또는 폭발할 수 있습니다. 누수된 배터리 액은 부식성 및 독성이 있기 때문에 피부나 눈에 화상을 입힐 수 있고 삼키면 몸에 해롭습니다. 부상의 위험을 줄이려면 다음 사항에 주의하십시오. <ul style="list-style-type: none">배터리를 어린이의 손이 닿지 않는 곳에 보관합니다. 배터리에 열을 가하거나 열거나 구멍을 내거나 자르거나 소각하지 않습니다. 새 배터리와 오래된 배터리 또는 다른 종류의 배터리를 함께 사용하지 않습니다(예: 망간 및 알카라인 배터리). 배터리를 거의 다 사용했거나 장시간 보관할 경우 해당 배터리를 제거합니다. 배터리 액이 누수되면 누수된 액이 피부나 옷에 묻지 않도록 주의하면서 배터리를 모두 제거합니다. 배터리 액이 피부나 옷에 묻으면 즉시 물로 씻어 냅니다. 새 배터리를 삽입하기 전에 물기 있는 휴지로 배터리 칸을 깨끗이 닦거나 배터리 제조업체의 세척 권장 사항을 따릅니다. 배터리 제조업체의 지침과 지역 및 국가별 폐기를 처리 규정에 따라 누수되거나 오래되거나 다 쓴 배터리를 폐기합니다.

다음 지침에 따라 배터리를 삽입하십시오.

유니버설 미디어 리모컨 설정

배터리 삽입

리모컨에 배터리를 삽입하려면 다음을 수행합니다.

- 리모컨 배터리 덮개를 제거합니다.
- 리모컨 배터리 덮개의 하단에 표시된 것과 같이 새 AA(LR6) 배터리 두 개를 삽입합니다. 최상의 성능을 얻으려면 AA 충전 배터리를 사용하지 않는 것이 좋습니다.
- 리모컨 배터리 덮개를 닫습니다.

TV에 맞게 유니버설 미디어 리모컨 프로그래밍

리모컨이 TV와 작동하도록 하려면 사용하고 있는 상표의 TV에 맞게 리모컨을 프로그래밍해야 합니다. 리모컨은 수동으로 TV 코드를 입력하거나 TV 코드를 검색하여 찾는 두 가지 방법을 사용하여 프로그래밍할 수 있습니다.

이 설명서 뒷부분에는 주요 TV 제품의 코드 목록이 있습니다. TV의 최신 코드 목록을 보려면 www.xbox.com/support를 방문하십시오.

참고

아무 작업도 하지 않은 채 30초가 지나면 작업이 중지됩니다. 0-9 또는 CH/PG 외의 단추를 누르면 리모컨이 원래 설정으로 복원됩니다.

TV 코드를 입력하려면 다음을 수행합니다.

- TV를 켜고 리모컨을 TV 쪽으로 가리킵니다.
- TV 단추와 OK 단추를 동시에 2초 동안 누르고 있습니다. 리모컨에 있는 모든 단추에 2 초 동안 불이 들어온 다음 숫자 단추(1-12)에만 불이 들어옵니다.
- TV 코드를 입력합니다.
- TV 단추를 다시 눌러서 코드를 저장하고 끝냅니다. 선택 내용을 확인하기 위해 리모컨에 있는 모든 단추가 세 번 깜빡입니다.

TV 코드를 검색하려면 다음을 수행합니다.

- TV를 켜고 리모컨을 TV 쪽으로 가리킵니다.
- TV 단추와 OK 단추를 동시에 2초 동안 누르고 있습니다. 리모컨에 있는 모든 단추에 2 초 동안 불이 들어온 다음 숫자 TV 단추(1-12)에만 불이 들어옵니다.
- CH/PG 단추를 TV가 꺼질 때까지 반복하여 누릅니다.

참고

각 단추를 누른 후 TV가 끄기 명령에 반응할 때까지 기다립니다. 끄기 명령에 반응하는 데 시간이 오래 걸리는 TV도 있습니다.

- TV 단추를 눌러서 코드를 저장하고 끝냅니다. 코드를 확인하기 위해 리모컨에 있는 모든 단추가 세 번 깜빡입니다.

참고

TV 코드를 설정한 후에 리모컨이 제대로 작동하지 않거나 기능이 불완전 또는 부정확하다면 같은 TV 제조업체의 다른 코드를 입력해 보거나 다른 코드를 검색해 보십시오. 3단계에서 TV 가 꺼진 다음 다른 코드를 검색하려면, TV를 켜고 4단계를 수행하기 전에 CH/PG 단추를 계속 눌러 다른 코드를 찾으십시오.

Xbox 360 유니버설 미디어 리모컨은 오직 TV와 Xbox 360 본체에만 사용할 수 있습니다. VCR, DVR, DVD 플레이어 또는 오디오 장비는 제어할 수 없습니다.


如果您需要更多幫助

如需一般問題的解答、疑難排解步驟以及 Xbox 客戶支援部門連絡資訊，請前往 www.xbox.com/support。

請勿將您的 Xbox 360 主機或其周邊配備拿到經銷商處要求維修，請至 www.xbox.com/support 參閱疑難排解與服務資訊。

⚠ 請勿嘗試自行維修
請勿嘗試拆解、維修或修改 Xbox 360 主機、電源供應器或其周邊配備。這麼做可能會產生電擊或火苗而導致嚴重傷害或死亡，而您的保固也將無效。

關於低功率射頻電機之注意事項

	經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。
---	--

重要電池資訊

	廢電池請回收。
---	---------

台灣地區的客戶本產品資訊

產品名稱：Xbox 360 多功能媒體遙控器
型號：多功能媒體遙控器
額定電壓：3 VDC
產地：中國
製造廠商：Microsoft Corporation
進口廠商：聯強國際股份有限公司
地址：台北市 104民生東路三段 75 號四樓
洽詢專線：(02) 2506-3320

著作權

本文件中的資訊（包括 URL 及其他網際網路網站參考資料）如有變更，恕不另行通知。除非另有註明，否則本文之範例公司、組織、產品、網域名稱、電子郵件地址、標章、人員、地點及事件均為虛構，並非意指任何真實公司、組織、產品、網域名稱、電子郵件地址、標章、人員、地點及事件。遵守所有適用的著作權法是使用者的責任。基於（但不限於）著作權法下之權利，未經 Microsoft Corporation 明示書面許可，貴用戶不得為任何目的使用任何形式或方法（電子形式、機械形式、影印、記錄或其他方法）複製、儲存或傳送本文件的任何部分或將本文件任何部分放入檢索系統 (retrieval system)。

Microsoft 可能就本文件所提及內容及文件標的擁有專利權、專利申請權、商標權、著作權、或其他智慧財產權。

除非 Microsoft 書面授權合約所明示規定者外，提供本文件並不授予貴用戶上述專利權、商標權、著作權或其他智慧財產權。

© 2011 Microsoft Corporation. 著作權所有，並保留一切權利。

Microsoft、Windows、Windows Media、Xbox、Xbox 360、Xbox LIVE、Xbox 標誌及 Xbox LIVE 標誌係 Microsoft 集團的商標。

유니버설 미디어 리모컨 사용

본 리모컨의 작동 방법은 TV 리모컨과 같습니다. 또한 Xbox 360 본체를 제어할 수 있으며 Windows Media Center 기반의 PC를 바로 사용할 수 있습니다.

컨트롤러 단추

리모컨에는 Xbox 가이드 단추와 A, B, X 및 Y 단추가 있는데, 이 단추들을 OK 단추와 함께 사용하여 컨트롤러를 사용하는 것처럼 Xbox 360 본체의 Xbox 가이드 및 Xbox 대시보드를 작동할 수 있습니다.

Windows Media Center 시작 단추

Windows Media Center 시작 단추를 사용하면 Xbox 360 본체를 통해 Windows Media Center 기반의 PC에 액세스할 수 있습니다. Xbox 360 본체에서 Windows Media Center를 사용할 수 있도록 설정한 경우 Windows Media Center 시작 단추를 누르면 Xbox 대시보드의 미디어 영역으로 이동할 수 있습니다. 아직 본체에서 Windows Media Center를 사용할 수 있도록 설정하지 않은 경우 이 단추를 누르면 Windows Media Center 설치 마법사가 시작됩니다.

본체의 전원이 꺼져 있는 경우 Windows Media Center 단추를 눌러서 본체를 켤 수도 있습니다.

리모컨 청소

마른 천이나 약간 물기 있는 천으로만 닦습니다. 세정액을 사용하거나 커넥터를 닦으면 리모컨이 손상될 수도 있습니다.

문제 해결

문제가 생긴 경우 아래 제공된 가능한 해결책을 시도해 보십시오.

DVD 기능이 작동하지 않습니다.

일부 DVD는 자막, 다국어 오디오 트랙, 다양한 카메라 각도, 느린 동작 재생 등 Xbox 360의 DVD 재생 기능을 모두 지원하지 않을 수도 있습니다. 지원되는 기능에 대한 자세한 내용은 DVD 제품 설명서를 참고하십시오. 드문 경우이지만 특정 DVD가 제대로 작동하지 않을 수 있습니다. 이것은 주로 DVD 비디오 소프트웨어의 제조 공정 또는 소프트웨어 인코딩의 변동 때문입니다.

비디오 또는 사운드 상태가 좋지 않거나 작동하지 않습니다.

AV 케이블이 제대로 연결되어 있는지 확인합니다. 설치 및 AV 문제 해결 정보는 Xbox 360 설치 설명서 또는 AV 케이블 지침을 참고하십시오.

단추가 작동하지 않습니다.

새 배터리로 리모컨을 테스트하여 배터리 상태를 확인합니다. 리모컨에서 배터리를 제거하고 모든 단추를 두 번 누른 다음 배터리를 다시 삽입해 보십시오.

특정 키가 작동하지 않는 경우 지침을 따라 리모컨을 청소하십시오.

Xbox 360 본체가 리모컨에 적절하게 반응하지 않습니다.

- 리모컨에 새 배터리가 들어 있는지 확인합니다.
- 리모컨으로 본체를 똑바로 가리킵니다.
- 주변에 전파를 송신 또는 수신하는 다른 장치가 있는지 확인합니다.
- 본체로부터 9미터 이내에서 리모컨을 사용 중인지 확인합니다.
- 주변의 적외선 영향을 최소화할 수 있도록 낮 시간에는 커튼이나 블라인드를 쳐 둡니다.


도움이 더 필요한 경우

일반적인 질문에 대한 답변, 문제 해결 절차 및 Xbox 고객 지원 센터 연락처 정보를 확인하려면 www.xbox.com/support를 방문하십시오.

수리 및 서비스를 받기 위해 Xbox 360 본체나 해당 액세서리를 판매점에 직접 가져가자 마십시오. 문제 해결 및 서비스 정보를 확인하려면 www.xbox.com/support를 방문하십시오.

⚠ 절대 수리하려고 하지 마십시오.
Xbox 360 본체, 전원 공급 장치 또는 주변 장치를 분해, 수리 또는 개조하지 마십시오. 감전이나 화재로 심각한 상해를 입거나 목숨을 잃을 수 있으며 보증도 무효가 됩니다.

배터리 및 전기/전자 장비 폐기물(WEEE) 처리

	제품 또는 제품 패키지에 이 기호가 있으면 해당 제품 또는 포함된 배터리는 가능한 분리 수거하거나 재활용될 수 있도록 알맞게 처리하는 것이 바람직합니다. 분리 수거와 재활용은 천연자원을 보존하고 인체와 환경에 미칠 수 있는 악영향을 방지하는 데 도움을 줍니다. 처리 방식이 올바르게 않으면 전기 및 전자 장비의 유해 물질로 인한 악영향에 피해를 입을 수 있습니다.
---	---

이 제품은 NRTL 목록(UL, CSA, FTL 등)에 등재 및/또는 IEC/EN 60950을 준수하는 (CE 마크) 정보 기술 장비와 함께 사용됩니다.

인증표시

- 모델명: Xbox 360 유니버설 미디어 리모컨
- 인증 받은자의 상호: Microsoft Corporation
- 제조연도: 2011 년
- 제조사/제조국가: Microsoft Corporation/China

대한민국 전자파 적합 등록 정보 등

- 이 기기는 가정용으로 전자파 적합 등록을 한 기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있음.
- 당해 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없음.

저작권

URL 및 기타 인터넷 웹 사이트 참조를 포함한 이 설명서의 내용은 예고 없이 변경될 수 있습니다. 다른 설명이 없는 한, 용례에 사용된 회사, 기관, 제품, 도메인 이름, 전자 메일 주소, 로고, 사람, 장소 및 이벤트 등은 실제 데이터가 아닙니다. 어떠한 실제 회사, 기관, 제품, 도메인 이름, 전자 메일 주소, 로고, 사람, 장소 및 이벤트와도 연관시킬 의도가 없으며 그렇게 유추해서도 안 됩니다. 귀하에게 적용되는 저작권법을 준수하는 것은 귀하의 책임입니다. 저작권에서의 권리와는 별도로, 이 설명서의 어떠한 부분도 Microsoft의 명시적인 서면 승인 없이는 어떠한 형식이나 수단(전자적, 기계적, 복사기에 의한 복사, 디스크 복사 또는 다른 방법) 또는 목적으로도 복제되거나, 검색 시스템에 저장 또는 도입되거나, 전송될 수 없습니다.

Microsoft는 이 설명서 주요 내용에 관련된 특허권, 특허출원, 상표권, 저작권 또는 기타 지적 재산권 등을 보유할 수 있습니다. 서면으로 체결된 라이선스 계약에 따라 Microsoft로부터 귀하에게 명시적으로 제공된 권리 이외에, 이 설명서의 제공은 귀하에게 이러한 특허권, 상표권, 저작권, 또는 기타 지적 재산권 등에 대한 어떠한 사용권도 허여하지 않습니다.

© 2011 Microsoft Corporation. All rights reserved.

Microsoft, Windows, Windows Media, Xbox, Xbox 360, Xbox LIVE, Xbox 로고 및 Xbox LIVE 로고는 Microsoft 그룹 계열사의 상표입니다.