

## Sony-Ericsson P800 Bluetooth Connections

You can use the Microsoft® Wireless Transceiver for Bluetooth® to transfer files, contacts, and other information between your Sony-Ericsson P800 mobile phone and your computer. For this to work correctly, you must first configure the computer and mobile phone to communicate with each other.

This document will help you configure your computer and your mobile phone to communicate over a Bluetooth connection, and step you through synchronizing your data.

These instructions assume that:

- You have already set up and configured your Microsoft Wireless Transceiver for Bluetooth on your computer.
- You have the PC Suite for P800 CD-ROM, or you have downloaded the latest version of PC Suite from the Support area at <http://www.sonyericsson.com>.
- You are running Microsoft Windows® XP with Service Pack 2 installed.

### To configure your phone for Bluetooth connections

- 1 Tap **Menu**, tap **Control Panel**, tap **Connections**, tap **Bluetooth**, and then tap **Settings**.
- 2 Set **Operation Mode** to **Discoverable**.
- 3 (Optional:) Enter a custom name for your phone, and then press **OK**.
- 4 Set **Receiving items** to **Always receive**.
- 5 Tap **Done**.

### To add your mobile phone to Windows as a paired Bluetooth device

- 1 On your computer, click **Start**, click **Control Panel**, click **Printers and other Hardware**, and then click **Bluetooth Devices**.
- 2 Click the **Options** tab.
- 3 Select the **Turn Discovery On** check box, and then click **Next**.
- 4 Select your mobile phone from the list of available devices, and then click **Next**.
- 5 Enter a passkey to send to your mobile phone, and then click **Next**. When prompted on your phone, enter the same passkey.
- 6 On the **Finish** screen of the wizard, make a note of the incoming and outgoing COM ports assigned to your phone's Bluetooth connection. You will use this information to configure your phone synchronization software in the following procedure.
- 7 On your mobile phone, tap **Menu**, tap **Control Panel**, tap **Connections**, tap **Bluetooth**, and then tap **Devices**.
- 8 Tap the name of your computer, and then select the **Allowed to connect without confirmation** check box.
- 9 Tap **Done** to save your changes.

### To install and configure PC Suite on your computer

For synchronization to work correctly, you must first install the PC Suite software and then configure it to communicate over a Bluetooth connection with your mobile phone.

- 1 On your computer, start the PC Suite installation from the CD-ROM or by double-clicking the .exe file downloaded from the Web.
- 2 Follow the setup instructions to install PC Suite on your computer.

- 3 After installation is complete, right-click the **Phone Connection Link** icon in the notification area (at the far right of the taskbar), and then click **Properties**.
- 4 Select the check box corresponding to the incoming COM port you wrote down in the preceding procedure, and then click **Close**.
- 5 Right-click the **Phone Connection Link** icon, and then click **Change Phone**.
- 6 Click **Refresh** to search for your phone's Bluetooth connection. When your phone is discovered, a new phone wizard will launch to help you configure your phone. After the wizard finishes, your mobile phone is ready for synchronization.
- 7 Click **Start**, point to **All Programs**, point to **Sony Ericsson**, point to **P800**, and then click **Sync Setup**.
- 8 Select the categories and applications that you want to synchronize.
- 9 To begin synchronization, click **Start**, point to **All Programs**, point to **Sony Ericsson**, point to **P800**, and then click **Synchronize**.

### Troubleshooting Tips

If you are having connection problems or synchronization problems with your mobile phone, try restarting your computer. This will help re-initialize the Bluetooth functionality on your computer. Once your computer has restarted, try synchronizing with your phone again.

For more information about connecting your devices or troubleshooting connection problems, see:

[Sony-Ericsson P800 Phone Support](#)

[Microsoft Help and Support](#)