

HP DeskJet 450wbt Bluetooth Connections

You can use the Microsoft® Wireless Transceiver for Bluetooth® to connect your HP DeskJet 450wbt printer and your computer. For this to work correctly, you must first configure the computer and printer to communicate with each other.

These instructions assume that:

- You have already set up and configured your Microsoft Wireless Transceiver for Bluetooth on your computer.
- You have assembled your printer according to the enclosed printer setup guide.
- You are running Microsoft Windows® XP with Service Pack 2 installed.

For more information, see the documentation that came with your printer.

To install your HP DeskJet printer

- 1 Make sure that your HP Bluetooth printer card is securely attached to the back of your printer, and that the LED indicator light is facing up.
- 2 Click **Start**, and then click **Printers and Faxes**.
- 3 Under **Printer Tasks**, click **Add a printer**.
- 4 In the Add Printer Wizard, click **Next**.
- 5 Click **A Bluetooth printer**, and then click **Next**.
- 6 Follow the instructions in the wizard to install the printer driver. If the Add Printer Wizard cannot locate an appropriate driver, you can browse the CD-ROM included with your printer to locate the correct file, hp450ka.inf.
- 7 Print a test page to verify a successful Bluetooth connection.

Troubleshooting Tips

If the Add Printer Wizard is having problems detecting your printer, check to see whether the HP Bluetooth printer card is securely attached and ensure that the green LED indicator light on the printer card is active.

If you are still having problems, try connecting the printer by using the enclosed cable first to verify that the printer is working correctly. After the printer is properly configured, you can try again to set it up by using a Bluetooth connection.

For more information about connecting your devices or troubleshooting connection problems, see:

[Hewlett-Packard printer support](#)

[Microsoft Help and Support](#)