

Nokia 7650 Bluetooth Connections

You can use the Microsoft® Wireless Transceiver for Bluetooth® to transfer files, contacts, and other information between your Nokia 7650 mobile phone and your computer. For this to work correctly, you must first configure the computer and mobile phone to communicate with each other.

This document will help you configure your computer and your mobile phone to communicate over a Bluetooth connection, and step you through synchronizing your data.

These instructions assume that:

- You have already set up and configured your Microsoft Wireless Transceiver for Bluetooth on your computer.
- You have the PC Suite for Nokia 7650 CD-ROM, or you have downloaded the latest version of PC Suite from the Support area at <http://www.nokia.com>.
- You are running Microsoft Windows® XP with Service Pack 2 installed.

To configure your phone for Bluetooth connections

- 1 Press **Menu**, press **Connectivity**, and then press **Bluetooth**.
- 2 (Optional:) Enter a custom name for your phone, and then press **OK**.
- 3 Set **Bluetooth** to **On**.
- 4 Set **My phone's visibility** to **Shown to all**.
- 5 Press **Exit** to return to the previous screen.

To install and configure PC Suite for Nokia 7650

- 1 On your computer, start the PC Suite installation from the CD-ROM or by double-clicking the .exe file downloaded from the Web.
- 2 Follow the installation instructions, including restarting your computer.
- 3 After the computer has restarted, click **Start**, point to **All Programs**, point to **PC Suite for Nokia 7650**, and then click **PC Suite for Nokia 7650**.

When the software starts for the first time, it prompts you to connect your mobile phone to the computer.

- 4 On your computer, click **Start**, click **Control Panel**, click **Printers and other Hardware**, and then click **Bluetooth Devices**.
- 5 On the **Devices** tab, click **Add**.
- 6 Follow the instructions in the Add Bluetooth Device Wizard to install your mobile phone. When prompted, you will need to enter a passkey on your mobile phone to accept the connection from your computer.
- 7 Write down the incoming and outgoing COM port number that you see on the **Finish** page. You will need this number to configure PC Suite in step 9.
- 8 Double-click the **mRouter** icon in the notification area, at the far right of the taskbar.
- 9 Select the check box corresponding to the incoming COM port you noted in step 7, and then click **Close** to return to PC Suite.
Note If you still get an error message that your device is not connected, try selecting another COM port in the mRouter settings screen
- 10 Return to the PC Suite for Nokia 7650 screen, and either enter a new custom name for your mobile phone or click **OK** to continue.

- 11 Follow the instructions in the PC Suite Wizard to customize what information will be synchronized with your mobile phone.
- 12 Once configuration has been completed, click **Synchronize** to begin synchronization with your mobile phone.

To configure your Nokia 7650 as an authorized device

When your mobile phone is authorized as a paired device with your computer, you do not have to accept a Bluetooth connection request on your phone each time you use PC Suite. Take the following steps:

- 1 Press **Menu**, press **Connectivity**, and then press **Bluetooth**.
- 2 Navigate to the **Paired Devices** tab.
- 3 Select the name of your computer, press **Options**, and then press **Set as authorized**.
- 4 Press **Yes** to confirm settings.

Troubleshooting Tips

For more information about connecting your devices or troubleshooting connection problems, see:

[Nokia 7650 Phone Support](#)

[Microsoft Help and Support](#)