



X18-36191-01

SURFACE POWER SUPPLY

CLEANING & USAGE INSTRUCTIONS

Always handle your accessory with care to maintain its appearance. To clean, wipe the outer surface with a soft, lint-free cloth.

 This symbol identifies safety and health messages in this Accessories Guide

WARNING: Read Safety & Health Info

Read this product guide and the guide for the device you are connecting this accessory to for important information and the terms of the Limited Warranty that apply to the Microsoft® device that you have purchased. Keep all printed guides for future reference. Failure to follow instructions and properly set up, use, and care for this product can increase the risk of serious injury or death, or damage to the device or devices. For an online version of this guide and additional support, go to: www.microsoft.com/surface/support

Warning: Do Not Attempt Repairs

Do not attempt to take apart, open, service, or modify the product, accessories, or power supply. Doing so could present the risk of electric shock or other hazard. Any evidence of any attempt to open and/or modify this device, including any peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

Warning: AC Adapter Safety

Failure to take the following precautions can result in serious injury or death from electric shock or fire or in damage to the device. To select an appropriate power source for your device:

- Use only the power supply unit and AC power cord that came with your device or that you received from an authorised Microsoft retailer.
- Do not use non-standard power sources, such as generators or inverters, even if the voltage and frequency appear acceptable. Only use AC power provided by a standard wall outlet.
- Do not overload your wall outlet, extension cord, power strip, or other electrical receptacle. Confirm that they are rated to handle the total current (in amps [A]) drawn by the device (indicated on the power supply unit) and any other devices that are on the same circuit.
- On devices where the AC prongs may be folded for storage, before plugging the AC adapter into a power outlet, make sure its prongs are fully extended.
- On devices where the AC prongs are removable and where the power supply uses a universal adapter, before plugging the AC adapter into a power outlet, make sure the prong assembly is of the proper configuration for the power outlet and fully seated into the adapter.

To avoid damaging the power cords and power supply:

- Protect the power cords from being walked on.
- Protect cords from being pinched or sharply bent, particularly where they connect to the power outlet, the power supply unit, and the device.
- Do not jerk, knot, sharply bend, or otherwise abuse the power cords.
- Do not expose the power cords to sources of heat.
- Keep children and pets away from the power cords. Do not allow them to bite or chew on them.
- When disconnecting the power cords, pull on the plug—do not pull on the cord.
- If a power cord or power supply becomes damaged in any way, stop using it immediately.
- Unplug your device during lightning storms or when unused for long periods of time.
- For devices with an AC power cord that connects to the power supply, always connect the power cord according to the following instructions:

1. Plug the AC power cord into the power supply until it seats fully.
2. Plug the other end of the AC power cord into the wall outlet.

Warning: Use Near Water

To reduce the risk of fire or shock, do not use this device near water and do not expose it to rain or moisture. Do not attempt to dry device with a hair dryer or a microwave oven.

Warning: Potentially Explosive Atmospheres


Areas with potentially explosive atmospheres are often, but not always, posted and can include fueling areas, such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders. When you are in such an area, turn off your mobile device, and do not remove or install battery chargers, AC adapters, or any other accessory. In such areas, sparks can occur and cause an explosion or fire.

Caution: Parts of this device are magnetic.

It may attract metallic materials. To reduce the potential risk of sparks, verify the electrical connection area is free of metallic objects before interconnecting devices. In order to reduce the likelihood of magnetic fields interfering with compass readings, disrupting the proper operation of pacemakers, or corrupting magnetically stored data, do not place credit cards or other magnetic storage media or magnetically sensitive devices near this device.

REGULATORY INFORMATION

Disposal of Waste Batteries and Electrical & Electronic Equipment

 This symbol on the product or its batteries or its packaging means that this product and any batteries it contains must not be disposed of with your household waste. Instead, it is your responsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. For more information about where to drop off your batteries and electrical and electronic waste, please contact your local city/municipality office, your household waste disposal service, or the shop where you purchased this product. Contact weee@microsoft.com for additional information on WEEE and waste batteries.

This device is not intended for use in machinery, medical or industrial applications. Any changes or modifications not expressly approved by Microsoft could void the user's authority to operate this device. This product is for use with NRTL Listed (UL, CSA, ETL, etc.), and/or IEC/EN 60950-1 compliant (CE marked) Information Technology equipment. No serviceable parts included. This device is rated as a commercial product for operation at +32°F (+0°C) to +104°F (+40°C).

Statement of Compliance with EU Directives

Hereby, Microsoft Corporation declares that this product is in compliance with the essential requirements and other relevant provisions of Directives, 2006/95/EC, 2004/108/EC. The technical documentation as required by the Conformity Assessment procedure is kept at the following address:

Microsoft Ireland Operations Ltd.
Carmenhall Road, Sandford Industrial Estate, DUBLIN 18
Ireland
+353 1 295 3826
+353 1 706 4110
<http://www.microsoft.com/ireland/>

ALIMENTATION ÉLECTRIQUE POUR SURFACE

INSTRUCTIONS RELATIVES AU NETTOYAGE ET À L'UTILISATION

Manipulez toujours votre accessoire avec soin pour préserver son apparence. Pour le nettoyer, essuyez la surface extérieure à l'aide d'un chiffon doux et non pelucheux.

 Ce symbole identifie des messages relatifs à la santé et à la sécurité dans ce Guide des Accessoires

AVERTISSEMENT : lisez les informations relatives à la santé et à la sécurité

Lisez ce guide produit et le guide pour l'appareil auquel vous connectez cet accessoire pour obtenir des informations importantes, ainsi que les dispositions de la Garantie Limitée, qui s'appliquent à l'appareil Microsoft® que vous avez acheté. Conservez tous les guides imprimés pour pouvoir vous y reporter ultérieurement. Le non-respect des instructions et l'incapacité à installer, utiliser et entretenir correctement ce produit peuvent accroître le risque de graves lésions corporelles, de mort ou de dommages au niveau du(des) appareil(s). Pour consulter ce guide en ligne et obtenir des informations supplémentaires relatives à la santé, rendez-vous sur : www.microsoft.com/Surface/support

Avertissement : ne tentez pas d'effectuer des réparations

Ne tentez pas de démonter, d'ouvrir, de réparer ou de modifier le produit, les accessoires ou le câble d'alimentation. Vous risqueriez de vous électrocuter ou de vous exposer à d'autres dangers. Tout signe de tentative d'ouverture et/ou de modification de cet appareil, y compris tout décollement, toute perforation ou tout retrait d'une étiquette, annulera la Garantie Limitée.

Avertissement : Consignes de sécurité pour l'adaptateur secteur

Le non-respect des précautions suivantes peut être à l'origine de graves blessures ou d'un décès suite à un choc électrique, à un incendie ou à des dommages liés à l'appareil. Pour sélectionner une source d'alimentation appropriée pour votre appareil :

- N'utilisez que le bloc d'alimentation et le cordon d'alimentation fournis avec votre appareil ou ceux qui vous ont été remis par un revendeur agréé Microsoft.
- N'utilisez pas de sources d'alimentation non-standards, comme des générateurs ou des onduleurs, même si la tension et la fréquence semblent convenir. N'utilisez que l'alimentation AC fournie par une prise murale standard.
- Ne surchargez pas votre prise murale, votre rallonge, votre multiprise ou tout autre prise électrique. Assurez-vous qu'elles sont signalées comme pouvant gérer le courant total (en ampères [A]) consommé par l'appareil (indiqué sur le bloc d'alimentation) et par tous les autres appareils qui se trouvent sur le même circuit électrique.
- Sur des appareils où les broches secteur peuvent être pliées pour être rangées, avant de brancher l'adaptateur secteur dans une prise électrique, assurez-vous que les broches sont totalement dépliées.
- Sur les appareils où les broches secteur sont amovibles et où l'alimentation électrique requiert un adaptateur universel, avant de brancher l'adaptateur secteur dans une prise électrique, veillez à ce que la configuration des broches soit adaptée à cette dernière et qu'elles soient bien enclenchées.

Pour éviter des dommages au niveau des câbles d'alimentation et de l'alimentation électrique :

- Protégez les câbles électriques pour que personne ne marche dessus.
- Protégez les câbles électriques de tout pincement ou de toute pliure excessive, en particulier lorsqu'ils sont branchés à la prise électrique, au bloc d'alimentation et à l'appareil.
- Ne tirez pas brusquement sur les câbles d'alimentation, ne les pliez pas à l'excès, ou ne les maltraitez pas de toute autre manière que ce soit.
- N'exposez pas les câbles d'alimentation à des sources de chaleur.
- Conservez les câbles d'alimentation hors des portées des enfants et des animaux. Ne les laissez pas les mordre ou les machouiller.
- Lorsque vous débranchez les câbles d'alimentation, tirez sur la prise. Ne tirez pas sur le câble.
- Si un câble d'alimentation ou un bloc d'alimentation est endommagé de quelque manière que ce soit, cessez immédiatement de l'utiliser.
- Débranchez votre appareil en cas d'orage ou en cas de non utilisation pendant une longue période.
- Pour les appareils disposant d'un câble d'alimentation secteur qui se branche au bloc d'alimentation, branchez toujours le cordon d'alimentation en suivant les instructions suivantes :

1. Branchez le cordon d'alimentation secteur dans le bloc d'alimentation jusqu'à ce qu'il soit totalement enclenché.
2. Branchez l'autre extrémité du cordon d'alimentation secteur dans la prise murale.

Avertissement : Utilisation à proximité d'un liquide

Pour réduire le risque d'incendie ou de choc, n'utilisez pas cet appareil à proximité d'un liquide et ne l'exposez pas à la pluie ou à de l'humidité. Ne tentez pas de sécher l'appareil en utilisant un sèche-cheveux ou un four à micro-ondes.

Avertissement : Atmosphères potentiellement explosives

Les zones avec des atmosphères potentiellement explosives sont souvent, mais pas toujours, signalées, et elles peuvent inclure des zones de ravitaillement comme les ponts inférieurs des bateaux, les installations pour le

Surface™

COPYRIGHT

Information and views expressed in this document, including URL and other Internet Web site references, may change without notice.

This document does not provide you with any legal rights to any intellectual property in any Microsoft product. You may copy and use this document for your internal, reference purposes. © 2012 Microsoft Corporation. Surface is a trademark of the Microsoft group of companies. Bluetooth is a registered trademark of Bluetooth SIG, Inc. All other trademarks are property of their respective owners.

MANUFACTURER'S WARRANTY

This Manufacturer's Warranty ("Warranty") is granted to You by Microsoft Ireland Operations Limited, Blackthorn Road, Sandford Industrial Estate, Dublin 18, Ireland ("Microsoft").

BY USING YOUR SURFACE PURCHASED FROM AN AUTHORISED RETAILER ("MICROSOFT HARDWARE"), OR MICROSOFT BRANDED ACCESSORY PURCHASED FROM AN AUTHORISED RETAILER ("ACCESSORY"), YOU AGREE TO THIS WARRANTY.

BEFORE USING IT, PLEASE READ THIS WARRANTY CAREFULLY. IF YOU DO NOT ACCEPT THIS WARRANTY, DO NOT USE YOUR MICROSOFT HARDWARE OR ACCESSORY. RETURN IT UNUSED TO YOUR RETAILER OR MICROSOFT FOR A REFUND. See www.microsoft.com/surface/warranty for more information.

This Warranty is distinct from any statutory product warranties owed by retailers and/or manufacturers under any national law applicable to You. It is intended to grant You specific, and as the case may be, additional rights, within the limits of what is permissible under such law, and not to restrict your rights under applicable statutory product warranty provisions. It cannot be transferred to any third party.

1. Warranty

- (a) For **one (1) year** from the date You purchased Your Microsoft Hardware or Accessory from an authorised retailer ("Warranty Period"), Microsoft warrants, only to You, that the Microsoft Hardware or Accessory will not malfunction due to a defect in materials or workmanship under Normal Use Conditions.
- (b) This is the only warranty Microsoft gives for Your Microsoft Hardware or Accessory. Microsoft gives no other guarantee, warranty, or condition. No one else may give any guarantee, warranty, or condition on Microsoft's behalf.
- (c) IF YOUR COUNTRY'S LAW GIVES YOU ANY IMPLIED WARRANTY, INCLUDING AN IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ITS DURATION IS LIMITED TO THE WARRANTY PERIOD. Some Countries do not allow limitations on how long an implied warranty lasts, so this limitation may not apply to You.
- (d) **Other Definitions.** "You" means the original end-user. "Normal Use Conditions" means ordinary consumer use under normal conditions according to the instruction manual.

2. Duration

Without prejudice to any statutory warranty to which You may be entitled under any local law applicable to You, and unless any such law provides for a longer term, Microsoft offers this Warranty, for a term of one (1) year from the purchase date of such Microsoft Hardware or Accessory from an authorised retailer.

3. Territory

This Warranty will be valid in the following countries only (including their overseas territories): United Kingdom, France, and Germany.

You acknowledge that specific export laws and regulations may apply to You depending on your country of residence and You agree to comply with all such laws and regulations if You export Your Microsoft Hardware or Accessory.

4. How to Get Warranty Service

- (a) Before starting the warranty process, please use the troubleshooting tips at www.microsoft.com/surface/support.
- (b) If the troubleshooting tips do not resolve Your problem, then follow the online process at www.microsoft.com/surface/warranty.
- (c) **Back up the Data or Programs Stored on Your Microsoft Hardware or Accessory and Delete Confidential Information.** Before sending Your Microsoft Hardware or Accessory to Microsoft or taking it to an authorised retailer for service, be sure to:
 - (i) BACK UP THE DATA OR PROGRAM STORED ON YOUR MICROSOFT HARDWARE OR ACCESSORY AND KEEP A COPY OF ANY DATA (INCLUDING PHOTOGRAPHS, DOCUMENTS, VIDEO, MUSIC, ETC.) OR PROGRAMS YOU WANT TO SAVE. MICROSOFT AND RETAILERS ARE NOT RESPONSIBLE FOR YOUR DATA OR PROGRAMS AND MAY ERASE THEM.
 - (ii) DELETE ANYTHING YOU CONSIDER CONFIDENTIAL. MICROSOFT AND RETAILERS ARE NOT RESPONSIBLE FOR YOUR PRIVACY IF YOU LEAVE CONFIDENTIAL INFORMATION ON YOUR DEVICE.

For more information, please see: www.microsoft.com/surface/warranty.

5. Microsoft's Responsibility

- (a) After You return Your Microsoft Hardware or Accessory to Microsoft or an authorised retailer, Microsoft or the retailer will inspect it.
- (b) If Microsoft or the retailer determines that the Microsoft Hardware or Accessory malfunctioned due to a defect in materials or workmanship during the Warranty Period under Normal Use Conditions, Microsoft or the retailer will (at its option) repair or replace it, or refund the purchase price to You, unless a mandatory provision of any local law applicable to You provides otherwise. Repair may use new or refurbished parts. Replacement may be with a new or refurbished unit.
- (c) After repair or replacement, Your Microsoft Hardware or Accessory will be covered by this Warranty for either the longer of the remainder of Your original Warranty Period, or 90 days after Microsoft or the retailer ships it to You.
- (d) UNLESS OTHERWISE PROVIDED UNDER ANY LOCAL LAW APPLICABLE TO YOU, MICROSOFT'S RESPONSIBILITY TO REPAIR OR REPLACE YOUR MICROSOFT HARDWARE OR ACCESSORY, OR TO REFUND THE PURCHASE PRICE, IS YOUR EXCLUSIVE REMEDY.
- (e) If Your Microsoft Hardware or Accessory malfunctions after the Warranty Period expires, there is no warranty of any kind. After the Warranty Period expires, Microsoft may charge You a fee for its efforts to diagnose and service any problems, whether such efforts are successful or not.

6. Warranty Exclusions

Microsoft is not responsible and this Warranty does not apply, even for a fee, if Your Microsoft Hardware or Accessory is:

- (a) damaged by use with products not sold or licensed by Microsoft;
- (b) opened, modified, or tampered with (including, for example, any attempt to defeat or circumvent any Microsoft technical limitation or security mechanism, etc.), or its serial number is altered or removed;
- (c) damaged by any external cause (including, for example, by being dropped, exposed to liquid, used with inadequate ventilation, etc., or failure to follow instructions in the instruction manual);
- (d) scratched, dented, etc. or shows other cosmetic damage; or
- (e) repaired by anyone other than Microsoft or an authorised retailer.

Microsoft does not guarantee that Your use of the Microsoft Hardware or Accessory will be uninterrupted, timely, secure, or error-free, or that data loss will not occur.

7. EXCLUSION OF CERTAIN DAMAGES

UNLESS OTHERWISE PROVIDED UNDER ANY LOCAL LAW APPLICABLE TO YOU, MICROSOFT IS NOT RESPONSIBLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES; ANY LOSS OF DATA, PRIVACY, CONFIDENTIALITY, OR PROFITS; OR ANY INABILITY TO USE YOUR MICROSOFT HARDWARE OR ACCESSORY. THESE EXCLUSIONS APPLY EVEN IF MICROSOFT HAS BEEN ADVISED OF THE POSSIBILITY OF THESE DAMAGES, AND EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. Some countries do not allow the exclusion or limitation of incidental or consequential damages, so this limitation or exclusion may not apply to You.

8. Additional Terms

If You attempt to defeat or circumvent any Microsoft Hardware or Accessory technical limitation or security system, You may cause Your Microsoft Hardware or Accessory to stop working permanently. You will also void Your warranty, and make Your Microsoft Hardware or Accessory ineligible for authorised repair, even for a fee.

9. Choice of Law

This Warranty will be subject to and construed in accordance with the law of Your country of residence, regardless of conflict of laws principles.


carburant, pour le transfert des produits chimiques ou pour le stockage, ou des zones où l'air contient des produits chimiques, des particules, comme de la poussière de céréales, ou des poudres de métaux. Lorsque vous êtes dans une zone de cette nature, éteignez votre appareil mobile, et ne retirez pas ou n'installez pas les chargeurs de batterie, les adaptateurs secteur ou tout autre accessoire. Dans de tels cas, des étincelles peuvent être générées et causer une explosion ou un incendie.

Attention : Cet appareil contient des pièces magnétiques.

Il peut attirer des matériaux métalliques. Pour réduire le risque potentiel d'étincelles, vérifiez que la zone de raccordement électrique n'est pas encombrée par des objets en métal avant de connecter les appareils entre eux. Pour éviter que des champs magnétiques causent des interférences avec des données de navigation, qu'ils gênent le bon fonctionnement des stimulateurs cardiaques, ou qu'ils endommagent des données stockées sur un support magnétique, ne placez pas de carte bancaire ou tout autre support de stockage magnétiques ou sensible aux champs magnétiques à proximité de cet appareil.

INFORMATIONS RÉGLEMENTAIRES

Élimination des piles et des équipements électriques et électroniques

 Ce symbole sur le produit, son emballage ou sur ses piles indique que le produit et les piles qu'il contient ne doivent pas être jetés avec vos ordures ménagères. Au contraire, vous êtes responsable de son/leur dépôt dans un point de collecte approprié pour le recyclage des piles et des équipements électriques et électroniques. Cette collecte et ce recyclage sélectifs permettront de protéger les ressources naturelles et de prévenir d'éventuelles conséquences négatives sur la santé et l'environnement qui pourraient être causées par une élimination inappropriée, ce en raison de la présence de matériaux dangereux contenus dans les piles ou les équipements électriques et électroniques. Pour obtenir de plus amples renseignements sur les points de collecte des piles et des équipements électriques et électroniques, veuillez contacter votre administration locale/mairie, votre service de ramassage d'ordures ménagères, ou le magasin où vous avez acheté ce produit. Contactez weee@microsoft.com pour en savoir plus sur l'élimination des piles et des équipements électriques et électroniques.

Cet appareil n'est pas destiné à une utilisation en milieu médical, technique ou industriel. Toute modification apportée à cet appareil sans avoir été expressément approuvée par Microsoft pourrait annuler le droit d'utiliser l'appareil. Ce produit est destiné à des équipements informatiques agréés NRTL (UL, CSA, ETL, etc.) et/ou conformes à la norme CEI/EN 60950-1 (marquage CE). Ne contient aucune pièce susceptible d'être réparée. Ce matériel est répertorié en tant que produit commercial conçu pour fonctionner à des températures allant de +0 °C à +40 °C.

Déclaration de conformité aux directives de l'UE

Par la présente, Microsoft Corporation déclare que ce produit est conforme aux exigences essentielles et aux autres dispositions applicables des Directives, 2006/95/CE et 2004/108/CE. La documentation technique, telle que requise par la procédure d'Évaluation de la conformité, est conservée à l'adresse suivante

Microsoft Ireland Operations Ltd.
Carmenhall Road, Sandford Industrial Estate, DUBLIN 18
Ireland
+353 1 295 3826
+353 1 706 4110
<http://www.microsoft.com/ireland/>

COPYRIGHT

Les informations et les points de vue exprimés dans ce document, y compris les URL et autres références à des sites Internet, pourront faire l'objet de modifications sans préavis.

Ce document ne vous donne aucun droit légal sur la propriété intellectuelle de tout produit Microsoft. Vous êtes libre de copier et d'utiliser ce document à des fins de références internes. © 2012 Microsoft Corporation. Surface est une marque commerciale du groupe de sociétés Microsoft. Bluetooth est une marque commerciale déposée de Bluetooth SIG, Inc. Toutes les autres marques commerciales sont la propriété de leur détenteur respectif.

GARANTIE FABRICANT ROYAUME-UNI, FRANCE ET ALLEMAGNE UNIFORMITÉ

La présente garantie fabricant (la « Garantie ») vous est accordée par Microsoft Ireland Operations Limited, Blackthorn Road, Sandford Industrial Estate, Dublin 18, Irlande (« Microsoft »).

EN UTILISANT VOTRE SURFACE ACHETÉE AUPRÈS D'UN DISTRIBUTEUR AGRÉÉ (« MATÉRIEL INFORMATIQUE MICROSOFT »), OU ACCESSOIRE DE MARQUE MICROSOFT ACHETÉ AUPRÈS D'UN DISTRIBUTEUR AGRÉÉ (« L'ACCESSOIRE »), VOUS ACCEPTEZ LES MODALITÉS DE LA PRÉSENTE GARANTIE.

AVANT DE L'INSTALLER, VEUILLEZ LIRE CETTE GARANTIE ATTENTIVEMENT. SI VOUS N'ACCEPTEZ PAS CETTE GARANTIE, N'UTILISEZ PAS VOTRE MATÉRIEL INFORMATIQUE MICROSOFT OU L'ACCESSOIRE. RESTITUEZ-LE SANS L'AVOIR UTILISÉ À VOTRE DISTRIBUTEUR OU À MICROSOFT POUR OBTENIR UN REMBOURSEMENT Consultez www.microsoft.com/surface/warranty pour de plus amples informations.

Cette Garantie est indépendante de toute garantie légale applicable en matière de produits due par les détaillants et/ou les fabricants en vertu du droit national qui Vous est applicable. Elle vise à Vous accorder des droits spécifiques et, le cas échéant, des droits supplémentaires dans la mesure où ledit droit le permet, et non pas à restreindre les droits dont Vous bénéficiez en vertu des dispositions des garanties légales applicables en matière de produits. Elle ne saurait être transférée à une tierce partie.

