

Setup Codes For Xbox 360 Media Remote (New)

3M	0724, 1145, 1616, 1655, 2508, 2838, 1143
888	0264, 0412
A-Mark	0003
A.R. Systems	0037, 0352, 0373, 0374, 0455, 1454, 1696
Abex	0039
Accent	0003, 0037
Accurian	1803
Acec	0012
Acer	1339, 1509, 1644, 2303, 2319, 2323
Acoustic Research	1196
Acoustic Solutions	1037, 1149, 1523, 1545, 1727, 2055
Action	0650, 0873
Acura	0003
ad notam	2723
ADB	1014
Adcom	0284
Addison	0092, 0150, 0653
ADL	0889, 1581, 2195
Admiral	0087, 0093, 0163, 0179, 0213, 0264, 0286, 0305, 0356, 0463
Advante	1531, 1885
Advent	0761, 1037, 0779, 0150, 0876, 1196, 1570, 1613, 1694
Adventura	0046
Adyson	0039, 0068, 0216, 0217
AEG	1037, 1149, 1324, 1046, 2021, 2096, 2166, 2197, 2165
Aftron	0748
Agashi	0216, 0217, 0264
AGATH	1740, 2107
AGB	0516
Agef	0087
Agfaphoto	1849
Aiko	0003, 0765, 0037, 0069, 0072, 0092, 0195, 0216, 0217, 0264, 0361, 0371, 0880, 1579, 1681
Aim	0037, 0068, 0455, 0499, 0706, 0753, 0805
Airis	0844, 1531, 2197, 1833, 1581, 2050, 1705, 2195, 2297, 1709
Aiwa	0039, 0701, 0768, 1180, 1229, 0154, 1904, 1910, 1911, 1915, 1916, 1976
Akai	0003, 0030, 0037, 0072, 0098, 0163, 0178, 0195, 0208, 0216, 0217, 0218, 0264, 0284, 0307, 0329, 0356, 0361, 0371, 0377, 0412, 0039, 0473, 0480, 0516, 0548, 1454, 0602, 0606, 0631, 0648, 0672, 0696, 2051, 0708, 0714, 0715, 0729, 0745, 0753, 0765, 0706, 1207, 1228, 1248, 0499, 1326, 1104, 1359, 1537, 1675, 1676, 1688, 1032, 1692, 1727, 1670, 2021, 2096, 2232, 2059, 1149
Akashi	0003, 0748
Akiba	0037, 0218, 0282, 0294, 0455
Akira	0190, 0418, 0753, 0858, 0765, 1037, 2032, 2333
Akito	0037, 0272
Akura	0003, 0037, 0171, 0218, 0264, 0282, 0283, 0412, 0668, 0714, 1037, 1363, 0835, 1046, 1149, 1709, 1770, 1820, 1847, 1506, 1983, 2165, 2289
Alaron	0179, 0183, 0216
Alba	0003, 0036, 0037, 0163, 0211, 0216, 0218, 0235, 0247, 0355, 0370, 0371, 0418, 0283, 0443, 0474, 0480, 0487, 0587, 0668, 0714, 1037, 1580, 1731, 1727, 1670, 1997, 2050, 2059, 2056, 1149
Albatron	0003, 0843
Alcyon	0076, 0211
Alfide	0672

Alien	1037
All-Tel	0865, 1196
Allorgan	0206, 0217, 0294
Allstar	0037
Alonsa	0858
Ambassador	0177
America Action	0180
Amitech	0655, 1281, 1782, 1849
Amoi	1486, 2988, 2989, 2993
Amplivision	0217, 0320, 0370, 0400
Ampro	0751
Amstrad	0003, 0037, 0163, 0171, 0177, 0218, 0264, 0039, 0440, 0362, 0371, 0412, 0516, 0648, 1037, 1820, 1890, 1506
Anam	0003, 0004, 0037, 0068, 0161, 0180, 0250, 0425, 0426, 0861
Anam National	0037, 0161, 0250, 0425, 0650
Andersson	1149, 1580
Anex	0416, 0421
Anglo	0003, 0264
Anhua	0051
Anitech	0003, 0037, 0068, 0076, 0264, 0282, 0474
Ansonic	0003, 0012, 0037, 0102, 0163, 0284, 0292, 0323, 0370, 0374, 0411, 0668, 1437, 1770
AOC	0003, 0018, 0019, 0030, 0052, 0060, 0092, 0093, 0150, 0137, 0178, 0179, 0180, 0185, 0451, 0474, 0625, 1089, 1365, 1589, 1590, 2014, 2087, 2111
Aolingpu	0858
Aolinpike	0264, 0412
Aomni	1623
Apex Digital	0748, 0765, 0879, 0890, 0889, 1709
Apollo	0473
Apro	1770
AquaVision	1606
Arc En Ciel	0109, 0196, 0333, 0103, 0568
Arcam	0216, 0217, 0103
Archer	0003
Archos	2503
Ardem	0037, 0714
Arena	0037
Aristona	0012, 0013, 0037, 1454
ART	1037
Art Mito	1580, 1820
Arthur Martin	0163, 0215, 0400, 0401
ASA	0070, 0087, 0105, 0179, 0295, 0346
Asambal	1046
Asberg	0037, 0076, 0102
ASDA	2126
ASK	1747, 0376
Asora	0003
Astar	1531, 1738
Astra	0037
Astro	0640
Asuka	0216, 0217, 0218, 0264, 0282
Asus	2175
ATD	0706
Atec	1606, 1728
Atlantic	0001, 0037, 0206, 0216, 0320
Atori	0003
Auchan	0163, 0215, 0400, 0401
Audinac	0180, 0391
Audiosonic	0003, 0037, 0109, 0217, 0218, 0264, 0337, 0348, 0370, 0374, 0486, 0714, 0715, 0820, 0858, 0865, 0499, 1675, 1681, 1703, 1802, 1983, 2050, 2059
Audioton	0217, 0264, 0370, 0486

Audiovox	0003, 0092, 0180, 0451, 0802, 0846, 0875, 1196, 1564, 1766, 1769, 1803, 1727, 1827, 1951, 1952, 2513, 3065
Audioworld	0706
Aumark	0060
AUO	1581
Auriga	1531
Aurora Systems	0801
Ausind	0076
Autovox	0076, 0087, 0206, 0217, 0247, 0286, 0295, 0336, 0349, 0544, 2059, 2172
AVC	2044
Aventura	0171
Avious	1634
Avol	1820
AVtex	2451
Awa	0003, 0011, 0036, 0150, 0216, 0217, 0264, 0374, 0451, 0606, 0779, 0883, 0888, 1376, 1681, 1985, 2039, 2032, 2480, 2157
Axion	1827, 1958
Axxent	0003
Axxion	2090
Axxon	0714
Baier	0876, 1324, 0898, 2165, 3024
Baihe	0003, 0264, 0412
Baile	0001, 0003, 0374, 0391, 0634
Baird	0005, 0072, 0073, 0109, 0190, 0192, 0208, 0217, 0343, 1196, 1709, 2059
Bang & Olufsen	0087, 0620, 1620
Baohuashi	0264, 0412
Baosheng	0003, 0150
Barco	0163, 0416, 1454
Base	0748, 1075, 1570
Baseline	1694
Basic Line	0003, 0037, 0163, 0217, 0218, 0282, 0208, 0374, 0455, 1454, 0668, 1037, 1149
Bastide	0217
Bauer	0805, 1615
Baumann Meyer	2051
Baur	0010, 0037, 0146, 0195, 0349, 0361, 0455, 0512, 0535, 0544
Baysonic	0180, 0236, 0463
Bazin	0217
BBK	0835, 2285
Beaumark	0178
Beijing	0001, 0003, 0208, 0226, 0264, 0374, 0391, 0412, 0482, 0634, 2051, 0150, 0765
Beko	0037, 0370, 0418, 0486, 0606, 0714, 0715, 0808, 0499, 1652, 0898, 2200
Belcor	0019
Bell & Howell	0016, 0017, 0154
Belson	0706, 0894, 1191, 2032
Belstar	1037
BenQ	1032, 1212, 1315, 1562, 1756, 1853
Bensten	1326, 0765, 1570, 1888, 1358, 1890, 1359, 1895
Beon	0039, 0037, 0418
Berthen	1454, 0668
Best	0337, 0370, 0421
Bestar	0037, 0370, 0374
Bestar-Daewoo	0374
Bestavision	0499, 0898
Bestwell	1326
Bexa	2493
BGH	0876, 0898
Binatone	0158, 0217

Black Diamond	0587, 0614, 0753, 0820, 0765, 1037, 1149, 1909
Black Panther	0102
Black Star	0247
Blackway	0218, 0282
Blaupunkt	0036, 0170, 0195, 0203, 0213, 0039, 0455, 0535
Blauren	0451
Blu:sens	1770, 2815
Blue Media	1606, 1728
Blue Sky	0037, 0218, 0282, 0455, 0487, 0499, 1454, 0451, 0625, 0668, 0714, 0715, 1037, 1149, 1191, 0765, 0898, 1363, 1324, 1521, 1598, 1652, 1709, 1739, 1771, 1916, 2153
Blue Star	0282
BlueDiamond	2059
BlueH	1745
Boca	1652
Boigle	1696
Boman	1324
Bondstec	0247
Boots	0003, 0217, 0233, 0272
Bork	1363
Bosch	0320
Boss Audio Systems	1186, 1440
Boxlight	0736
BPL	0037, 0208, 0282, 0373, 0896, 1046, 1227, 0499, 1440, 1443, 1472, 1543, 2656
Bradford	0180
Brandt	0103, 0109, 0196, 0287, 0333, 0335, 0560, 0568, 0625, 0714
Brandt Electronique	0109, 0568
Brandt Plus	1851
Braun	0366
Brilliant	1007, 1255
Brimax	1709, 2386
Brinkmann	0037, 0418, 0486, 1037, 0668
Brionvega	0037, 0087, 0362, 1608, 2091
Bristol	2090
Britannia	0216, 0217
Brockwood	0019
Broksonic	0003, 0236, 0426, 0463, 0642, 1905, 1911, 1929, 1670, 1938
Brother	0264, 0796
Bruns	0087, 0297
BSR	0163, 0294
BTC	0218
Bush	0003, 0036, 0037, 0204, 0208, 0211, 0217, 0218, 0235, 0264, 0272, 0282, 0284, 0294, 0349, 0355, 0361, 0356, 0371, 0374, 0443, 0487, 0401, 1454, 0587, 0614, 0660, 0634, 0668, 0706, 0714, 0778, 1037, 1149, 1166, 0765, 1248, 0499, 1421, 0655, 1473, 1046, 1580, 1634, 0835, 1652, 1682, 1731, 1727, 1869, 0753, 1871, 1900, 1938, 1506, 1983, 2032, 2043, 2050, 2053, 2055, 2056, 2060, 2059, 0898, 2212, 1589, 1720, 2165
Byd:sign	1309, 1196, 1486, 2140, 2209
C & M	0003
C-Tech	0858, 0748, 0896
Cadia	1283
Cai Xing	1006
Caihong	0003, 0150
Cailing	0748
Caishi	0748
Cameron	1523, 2265, 2055
Camper	0037
Canca	1326

Candle	0030, 0046, 0056, 0186
Canon	0376, 1396, 2590, 2610, 2743
Canton	0218
Capehart	0052
Capetronic	0003, 0030, 0309
Capsonic	0264
Carad	0610, 0668, 1037
Carena	0037, 0455
Carnivale	0030
Carrefour	0036, 0037, 0070
Carver	0054, 0170
Cascade	0003, 0037
Casio	0037, 0611, 1205, 1624
Cat	1682, 2090
Cathay	0037, 0474, 1727
CCE	0037, 0217, 0329, 0451
CE	1046
Celebrity	0000
Celera	0765
Celestial	0765, 0819, 0820, 3052, 1709
cello	1770, 1802, 1820, 1845, 2673
Centrex	0748, 0706, 1075, 1203, 1536, 1626, 1731, 2423
Centrum	1037
Centurion	0037
Century	0087, 0213, 0238, 0247
CGE	0074, 0076, 0163, 0247, 0370, 0418
Champion	0154
Changcheng	0001, 0003, 0051, 0264, 0374, 0391, 0412, 0634, 0150
Changfei	0003, 0329, 0374, 0150
Changfeng	0264, 0412, 0696, 0753, 0150
Changhai	0003, 0329, 0150
Changhong	0003, 0156, 0264, 1037, 0765, 0150, 0819, 0820, 0768, 0499, 1033, 0835, 1910, 1589, 2894, 2972, 2978, 2984, 3016
Chengdu	0003, 0150
Chimei	1666, 1852, 2290
Ching Tai	0003, 0092, 0179, 0474
Chun Yun	0000, 0003, 0033, 0092, 0161, 0179, 0180, 0474, 0706, 0843, 0150, 0835, 1756, 0466, 2230, 2317
Chunfeng	0003, 0264
Chung Hsin	0033, 0036, 0053, 0150, 0180, 0474
Chungfeng	0412, 0646
Chunsun	0003, 0150
Cimline	0003, 0218
Cinago	1986
Cinema	0672
Cineral	0092, 0451
Cinetec	2060
Cinex	0648, 1166, 1046, 1506
Citizen	0030, 0039, 0046, 0056, 0060, 0092, 0180, 0186, 0280, 0451, 0535, 0561, 0802, 1671, 1672, 1928, 1670
City	0003
Clairtone	0185
Clarion	0180
Clarivox	0037, 0070, 0102, 0297, 0337, 0418, 1624
Classic	0499, 1900
Clatronic	0003, 0037, 0076, 0102, 0217, 0218, 0247, 0264, 0320, 0370, 0371, 0714, 1324, 1677, 2594
Clayton	1037
CME	0640, 1624
CMS	0216
CMS Hightec	0217
CMX	2797, 2798, 2799, 2471

Coby	1538, 1634, 2017, 2306, 2314, 2315, 2326, 2338, 2340, 2343, 2344, 2345, 1802, 1738, 2351, 2560
Commercial Solutions	0047
Compacks	1792, 1949
Compaq	0749, 0750
Concerto	0056
Concorde	0003
Condor	0003, 0037, 0102, 0216, 0247, 0264, 0282, 0314, 0320, 0370, 0411, 0418
Conia	0754, 0820, 0765, 0894, 1211, 0835, 1523, 1626, 2032, 2410
Conic	0039
Conrac	0808
Conrowa	0003, 1145, 0156, 0264, 0412, 0642, 0696, 0706, 0753, 0170
Contec	0003, 0036, 0037, 0158, 0180, 0185, 0216
Continental	1885
Continental Edison	0103, 0109, 0196, 0287, 0333, 0487, 0568, 0654
Coradir	2157
Cosmel	0003, 0037, 0337
CPTEC	0625, 1363
Craig	0161, 0180
Crezar	0213
Croma	1037, 1843, 2399
Crosley	0000, 0054, 0074, 0076, 0087, 0163, 0213, 0247
Crown	0003, 0037, 0039, 0053, 0068, 0076, 0180, 0208, 0370, 0373, 0412, 0418, 0421, 0486, 0487, 0606, 0668, 0672, 0712, 0714, 0715, 1037, 1446, 1652, 2021, 0896
Crown Mustang	0068, 0672
Crystal	0283
CS Electronics	0216, 0218, 0247, 0414
CTC	0247
CTX	0003, 1756
Curtis	1200, 1326, 2259, 2032, 1709
Curtis Mathes	0016, 0030, 0039, 0047, 0051, 0054, 0056, 0060, 0068, 0093, 1145, 0154, 0166, 0451, 0466, 2051, 0747, 1347, 1919, 1959
CWN	1367, 1416
CXC	0180
CyberHome	0794, 1176
Cyberpix	1149
Cybertron	0218
Cytron	1326, 1802
Cytronix	1298
D-Vision	0037, 1454, 1506
Daas	0297
Daenyx	0179, 0180, 0672
Daewoo	0003, 0004, 0019, 0030, 0037, 0039, 0056, 0066, 0067, 0091, 0092, 0150, 0154, 0170, 0178, 0180, 0216, 0217, 0218, 0374, 0391, 0402, 0451, 0474, 0499, 0627, 0634, 0672, 0778, 0841, 0748, 0865, 0876, 0880, 1454, 1203, 1266, 1376, 1598, 1606, 1612, 1795, 1816, 1849, 1909, 1921, 1928, 2098, 2333
Daijitsu	2804
Dainichi	0215, 0216, 0218
Daitso	2051
Dansai	0003, 0039, 0765, 0036, 0037, 0208, 0216, 0217
Dansette	0412
Dantax	0370, 0486, 0714, 0715, 1037, 1149, 1652, 1916, 2060
Datsura	0208, 0373
Davis	0736
Dawa	0003, 0037

Daytek	0672, 1207, 1376
Dayton	0003, 1207
Daytron	0003, 0019, 0037, 0180, 0374
Dayu	0374, 0391, 0634
De Graaf	0044, 0163, 0208, 0356, 0548
DEC	0779, 0795, 0748, 1326, 1709
Decca	0033, 0037, 0072, 0217, 0272, 0516
Deitron	0374
Dell	1454, 0178, 1264
Denko	0264
Denon	1145, 0511
Denstar	0180
Denver	0037, 0587, 1189, 1634, 1677, 1709, 1770, 1820, 1988, 2021, 2050, 2096, 2139, 2172, 2197, 2062, 1845, 2594
DER	0190
Derwent	0201
Desmet	0003, 0037, 0087, 0320
Dewo	0180
DGM	1435, 1890, 2020, 1581, 2059, 2165, 2282, 2283, 2062, 3045
Diamant	0037
Diamond	0003, 0216, 0371, 0672, 0706, 0804, 0820, 0825, 0748, 0896
Diamond Vision	1996, 1997
DiBoss	0499, 1046
Dick Smith Electronics	0706, 1261, 1326, 1046, 1660, 0753, 1985, 1802, 2032, 1739
Digatron	0037
Digihome	1149
Digiline	0037, 0105, 0668
DigiLogic	2126
Digimate	0890, 2020, 1581
DigiMax	0748
Digisonic	1826
Digistar	0773
Digital Device	1606
Digital Life	0748, 0872
Digital Lifestyles	1546, 1822
Digital Projection Inc.	1725, 1726, 1750
Digitek	1521, 1709, 1771
Digitex	0820, 0765
Digitor	0037, 0706, 0888, 1497, 1703, 0003, 1985
Digitrex	2056, 2165
Digix Media	0880
Dikom	1696, 1703
DirecTV	1501
Dish Network	1948
Disney	0171, 1440, 1997
Diunamai	1359
diVision	2165
Dixi	0004, 0003, 0037, 0087, 0217, 0247, 0297
DK Digital	1662, 1942
DL	0587, 0748, 0768, 0872, 1203, 1326, 1363
DMTech	1338, 1898, 1827, 1964, 2001, 2154, 2251, 1709
Doma	2694
Domeos	0668
Domland	0394
Dongda	0003
Donghai	0003
Doric	0201
Dream Screen	0654
Dream Vision	0673, 1297, 1398
Drean	0037
DSE	0706, 0765, 0820, 0888, 0003, 1166, 1261, 1326,

	1497, 1046, 1248, 0773, 1376, 1660, 1703, 0753, 1985, 1802, 2090, 2032, 2098, 2475, 2480, 2484, 1739
DTS	0003
Dual	0037, 0217, 0336, 0343, 0349, 0352, 0394, 0103, 0544, 0778, 1037, 0640, 1149, 2051, 2032
Dual Tec	0217
Dumont	0017, 0019, 0070, 0072, 0087, 0102, 0213, 0217, 0295
Durabrand	0003, 0171, 0178, 0180, 0463, 1034, 1037, 1437, 1652, 2197, 1988, 2126
Dux	0012, 0037
DVX	0748
Dwin	0720, 0747, 0774
DX Antenna	1817
Dynaconnective	2811
Dynatech	0217
Dynatron	0012, 0037
Dynex	0463, 1710
Dyon	2032, 2882, 2909, 2911
e-motion	1709
E-Zipy	2069
E:max	1324, 1531
Easy Living	0877, 1166, 0889, 1248, 0499, 1613, 1376, 1666, 1709, 0443, 2023, 2030, 2059, 1578, 2090, 2157, 2252, 2253, 2255, 2258
Ecco	0773
ECE	0037, 1046, 0748
Ectec	0391
Edison-Minerva	0487
Eiki	0376, 2455, 2600
Elba	1557
Elba-Sharp	0516
Elbe	0037, 0195, 0217, 0218, 0238, 0284, 0292, 0362, 0411, 0516, 1454, 0610, 0716
Elcit	0087, 0102, 0163, 0247, 0307, 0516
Electra	0876
Electroband	0000, 0185, 0039
Electrograph	1623, 0755
Electrohome	0036, 0039, 0463, 1067, 1570, 1670, 1672
Electroview	1531, 2706
Elekta	0003, 0264, 0282
Elektra	0017, 0451
Elektronska	0307
Element	0835, 1817, 0178
Elenberg	2055, 1769
Elfunk	1037, 0208
ELG	0037
Elin	0003, 0037, 0305, 0349, 0361, 0039, 0548
Elite	0037, 0218, 0320
Elman	0102
Elonex	1745
Elta	0003, 0068, 0264, 0283, 0474, 1662, 1942
Eltoc	0765
Emco	0247
Emerson	0001, 0019, 0037, 0038, 0039, 0070, 0087, 0154, 0158, 0171, 0177, 0178, 0179, 0180, 0181, 0036, 0183, 0185, 0213, 0236, 0247, 0270, 0280, 0282, 0320, 0361, 0370, 0371, 0451, 0463, 0486, 0668, 0714, 1817, 1905, 1909, 1911, 1904, 1928, 1929, 1944, 1997
Emperor	0282
Emprex	1422, 1546, 1789
Emtek	0748
Encross	0876, 1046

Energy Sistem	0874
Engel	1624
Envision	0030, 0813, 1365, 1506, 1589, 2014, 2087
Enzer	0068, 0753, 0748, 1572
Epson	1122, 1290, 1379
Erae	1222, 1191
Erisson	1682
Erres	0012, 0037
ESA	0171, 2051, 1944
ESC	0037, 0217, 0474
Esonic	2221, 0156, 1422
ESP	0164
Ether	0003, 0030, 0161
Etron	0001, 0003, 0163, 0283, 0646, 0820, 1855
Eurofeel	0217, 0264, 0464, 0654
EuroLine	2050, 0753
Euroman	0037, 0216, 0217, 0264, 0370, 0421
Europa	0037
Europhon	0037, 0102, 0213, 0217, 0307, 0314, 0283, 0516
Evesham	1248, 1536, 1606, 1149, 2885, 1728
Evesham Technology	1728
Evolution	1756
Evotel	2559, 2062
eWindows	2880
Excello	1037, 1326
Excors	1696
Expert	0163, 0206, 0215, 0305, 0400, 0401
Exquisit	0037, 0247
FairTec	1373
Fast	1901
Feilang	0003
Feilu	0003, 0150
Feiyan	0264, 0412
Feiyue	0003, 0150, 1044
Fenner	0003, 0374
Ferguson	0005, 0037, 0053, 0073, 0109, 0190, 0192, 0195, 0238, 0287, 0295, 0335, 0343, 0443, 0548, 0560, 0625, 1037, 1471, 1580, 1727, 1670, 1938, 2053, 1581, 2090, 1578, 0451, 2393
Fidelity	0037, 0082, 0163, 0171, 0216, 0264, 0361, 0356, 0371, 0412, 0474, 0512, 1037, 0544
Filsai	0217
Finlandia	0072, 0163, 0208, 0346, 0361, 0356, 0548
Finlux	0037, 0070, 0072, 0087, 0102, 0105, 0163, 0179, 0217, 0295, 0314, 0346, 0411, 0473, 0480, 0516, 1454, 0631, 0714, 0715, 0808, 1166, 1248, 1046, 1149
Firststar	0003, 0033, 0236
Firstline	0003, 0037, 0068, 0072, 0102, 0208, 0216, 0217, 0235, 0238, 0247, 0294, 0314, 0349, 0361, 0374, 0411, 0544, 1454, 0451, 0668, 0714, 0808, 1037, 1191, 0499, 1363, 0898, 1612
Fisher	0036, 0047, 0072, 0087, 0154, 0159, 0208, 0217, 0297, 0349, 0361, 0370, 0544, 1624
Flatdisplays	0874
Flint	0037, 0072, 0218, 0264, 0455, 0610
Fluid	2877
FNR	0102
Foehn & Hirsch	1531
Fonda	1239
Force	1149
Formenti	0037, 0076, 0087, 0163, 0213, 0216, 0320
Formenti-Phoenix	0216, 0320
Fortress	0087, 0093
Fraba	0037, 0370

Fredomatic	0461
Friac	0003, 0037, 0102, 0370, 0421, 0499, 0610
Frigidaire	0755, 1826, 2231, 2363, 0706
Frontech	0003, 0163, 0217, 0247, 0264, 0356, 0414, 0283, 0039, 0474
Fujicom	1273, 1626, 1709, 1792, 1820
Fujimaro	0865, 0835
Fujimaru	0835
Fujitsu	0003, 0072, 0095, 0102, 0179, 0186, 0206, 0217, 0314, 0352, 0683, 0809, 0853, 1181, 1607, 2008
Fujitsu General	0003, 0186, 0206, 0217, 0683
Fujitsu Siemens	0808, 0809, 1149, 1248, 1298, 1373, 1666, 2174
Funai	0000, 0171, 0179, 0180, 0264, 0294, 0342, 0668, 0714, 0804, 1037, 1281, 1666, 1817, 1904, 1944, 1977, 2861
Furi	1145, 0264, 0412, 0150
Furichi	0748
Futarque	2188
Futronic	0264, 0795, 0748, 1531
Futuretech	0180
G-Hanz	1363, 0755, 2449
G-Hanz Sampo	0755
Gaba	0858, 1037, 1183
Galaxi	0037
Galaxis	0037, 0370
Ganxin	0150
Gateway	0755, 1756
GBC	0003, 0163, 0213, 0218, 0374
GE	0021, 0027, 0029, 0030, 0047, 0051, 0092, 0093, 0135, 0178, 0180, 0279, 0282, 0335, 0451, 0560, 0625, 0376, 0747, 0765, 1347, 1454, 1907, 0818, 1919, 1922, 2359
Geant Casino	0215, 0400, 0401
GEC	0037, 0043, 0072, 0163, 0217, 0349, 0361, 0516
Geloso	0003, 0163, 0213, 0247, 0356, 0374
General	0109, 0186, 0287, 0471
General Electric	0021, 0027, 0047, 0180
General Technic	0003
Genesis	0003, 0037
Genexxa	0003, 0037, 0163, 0218, 0412
Gericom	0808, 0865, 0880, 1206, 0889, 1298, 1606, 1731
Germanvox	0213
Gevalt	1191
GFM	0171, 1817, 1944
Giant	0003, 0217
Gibraltar	0017, 0019, 0030
Gibson	0755, 1826, 0466, 2299, 2305
Gilma	2449
Gintai	0440, 0474, 0721, 0150
Global Home	0156, 0773
Go Video	0060, 0886, 1738, 1831
Godrej	1580
Gold	1770, 1833, 2023, 2039, 2077, 2079, 2081, 2082, 1672, 0802, 2090, 2157
Gold Vision	0634
Goldfunk	0668
GoldHand	0216
Goldline	0337
GoldStar	0001, 0019, 0030, 0037, 0039, 0044, 0056, 0109, 0154, 0163, 0178, 0216, 0217, 0247, 0283, 0308, 0361, 0356, 0377, 0455, 0457, 0474, 0606, 0714, 0715, 0150, 1910, 1920, 1926
Gooding	0487
Goodmans	0003, 0765, 0036, 0037, 0072, 0179, 0217, 0218, 0235, 0264, 0039, 0335, 0343, 0360, 0371, 0374,

	0480, 0487, 0499, 0516, 1454, 0560, 0451, 0625,
	0634, 0668, 0714, 0808, 0880, 1037, 1149, 1248,
	1376, 1523, 0835, 1682, 2885, 1720, 1727, 1795,
	1841, 1871, 1872, 1900, 1909, 1916, 1949, 1983,
	1985, 2053, 2055, 2056, 0753, 1709, 2393
Gorenje	0370, 0421
GP	0753
GPM	0218
GPX	0179, 2259
Gradiente	0037, 0053, 0056, 0170, 0392, 1804
Graetz	0163, 0208, 0361, 0371, 0487, 0714, 1149
Gran Prix	0648, 2333, 2336
Granada	0012, 0036, 0037, 0072, 0076, 0150, 0146, 0163,
	0201, 0208, 0215, 0217, 0226, 0343, 0356, 0400,
	0473, 0516, 0548, 0560
Grandin	0003, 0037, 0163, 0215, 0218, 0282, 0320, 0374,
	0400, 0401, 0455, 1454, 0610, 0451, 0668, 0714,
	0715, 0865, 0880, 1037, 1191, 1206, 1298, 1207,
	1375, 1377, 1380, 0898, 1652
Griffin	0310
Gronic	0102, 0217, 1624
Grundig	0003, 0036, 0037, 0070, 0195, 0215, 0422, 0443,
	0487, 0535, 1454, 0587, 0672, 0683, 0706, 1166,
	1223, 1248, 0499, 1191, 1376, 1582, 1149, 1869,
	1871, 1876, 1916, 1670, 1938, 2053, 2059, 2060,
	0898, 0835, 1324, 2195, 2200, 2165, 2307, 1037
Grunkel	1149
Grunpy	0179, 0180
GVA	1075, 1326, 1363, 2098
H & B	0808, 1206, 2001
Haaz	0706
Haier	0037, 0765, 0587, 0706, 0768, 0779, 0869, 0748,
	0896, 1009, 1017, 1019, 1034, 1052, 1057, 1061,
	1062, 1067, 1090, 1203, 1238, 1570, 1615, 0178,
	1983, 2134, 2212, 0867, 2449, 2494, 2690, 2812
Haihong	0003
Haiyan	0264, 0412, 0150
Halifax	0216, 0217, 0264
Hallmark	0178
Hami	2069
Hampton	0216, 0217
Hanimex	0218, 0294, 1908
Hankook	0019, 0030, 0056, 0178, 0180, 0039
Hanns.G	1613, 2298, 2304
Hannspree	1348, 1352, 1613, 1745, 1826, 2027, 1589, 2298,
	2304
Hanseatic	0003, 0037, 0087, 0213, 0217, 0282, 0292, 0294,
	0320, 0336, 0349, 0361, 0370, 0373, 0377, 0394,
	0283, 0499, 1037, 0401, 0544, 1454, 0625, 0634,
	0714, 0808, 1964, 2001
Hansol	1046
Hantarex	0003, 0037, 0102, 0213, 0238, 0307, 0516, 0829,
	0865, 1338, 1465, 1466, 2131, 2132, 2197, 2062,
	2406, 2467
Hantor	0037
Harley Davidson	0043, 0179, 1904
Harman/Kardon	0054
Harsper	0865, 1206
Harvard	0068, 0180
Harwa	0773, 1196
Harwood	0003, 0037, 0039, 0412, 0487
Hauppauge	0037
Havermy	0093
HB	1324, 2353
HCM	0003, 0037, 0217, 0218, 0264, 0282, 0412, 0418,

	0601, 1196
Helios	0865
Hello Kitty	0451, 1997
Hema	0003, 0217
Hemmermann	0349, 0544
Heran	1826, 1852, 2305, 2356
Herosonic	1826
Hewlett Packard	1088, 1089, 1101, 1494
Hicon	1298, 2410
Hifivox	0109, 0196, 0103, 0568
Higashi	0216
Highlander	1531
Highline	0037, 0264
Hikato	0180
Hikona	0218, 0474, 1983
Himitsu	0180, 0779
Hinari	0003, 0036, 0037, 0179, 0208, 0211, 0218, 0235, 0264, 0283, 0294, 0355, 0406, 0443, 1624, 1908
HiPlus	1420, 1435, 1826, 2113, 2410, 2226, 2230, 2235, 2253, 2287
Hisawa	0218, 0039, 0282, 0400, 0455, 0610, 0714
Hisense	0003, 1145, 0156, 0183, 0208, 0044, 0765, 1454, 0696, 0748, 0753, 0004, 0768, 1006, 1022, 1069, 1071, 0264, 1075, 1076, 1077, 1078, 1079, 1081, 1082, 1083, 0170, 0898, 1363, 1660, 1739, 2037, 2098, 0178, 2341, 2399, 3010, 3120
Hiss Electronics	2827
Hit	0087
Hitachi	0003, 0016, 0019, 0027, 0030, 0036, 0037, 0038, 0039, 0043, 0044, 0056, 0072, 0092, 0095, 0096, 0097, 0105, 0109, 0150, 0151, 0156, 0163, 0165, 0173, 0178, 0179, 0186, 0194, 0196, 0213, 0217, 0225, 0279, 0343, 0349, 0356, 0413, 0473, 0474, 0480, 0499, 0765, 0516, 0548, 0578, 0583, 0634, 0723, 0724, 0744, 0797, 0877, 1037, 0640, 1145, 1149, 1155, 0170, 1484, 1500, 1576, 1580, 1904, 1670, 0443, 2074, 0835, 1589, 1682, 1506, 2838, 2995
Hitachi Fujian	0150, 0828, 0748
Hitec	0706
Hitech	0753
Hitsu	0003, 0218, 0455, 0610
HMV	0087
Hoeher	0714, 0865, 1149, 1046
Home Electronics	0606
HomeTech	2462
Hongmei	0003, 0093, 0264, 0150, 0768, 1910
Hongyan	0264, 0412, 0150
Horizont	1617, 3024
Hornyphon	0012, 0037
Hoshai	0218, 0282, 0455
HP	1088, 1089, 1101, 1494
Hua Tun	0003, 0150
Huafa	0003, 1145
Huanghaimei	0003
Huanghe	0003, 0150
Huanglong	0003
Huangshan	0003, 0264, 0412, 0150
Huanyu	0216, 0044, 0264, 0374, 0150, 0768, 1910
Huaqiang	0264, 0412
Huari	1145, 0264, 0412
Hugoson	0890, 0889, 1666, 2195
Humax	1295, 1501
Huodateji	0051
HYD	1376

Hygashi	0216, 0217
Hyper	0003, 0216, 0217, 0247
Hypersonic	0361
Hypson	0037, 0217, 0264, 0282, 0400, 0455, 0486, 1454, 0668, 0714, 0715, 1037
Hyundai	0706, 0753, 0765, 0778, 0803, 0849, 0748, 0865, 0876, 0888, 1006, 1037, 1152, 1281, 1294, 1326, 1376, 1468, 1377, 1523, 1531, 1532, 1046, 1248, 1594, 1598, 1606, 1612, 1681, 1694, 1720, 1770, 1820, 2139, 2154, 2062, 2296, 2454, 2460
I-Inc	1746
i-Joy	2252
I-O Data	2977
Iberia	0037
ICE	0037, 0216, 0217, 0218, 0264, 0371
ICeS	0216, 0218
iDEAL	1046
Iekei	1696
Igo	0653
IISonic	1376, 1513, 1613
Iiyama	0877, 0890, 0889, 2159
iLo	1381, 0171, 2417, 1684, 1990
Imperial	0037, 0074, 0076, 0196, 0247, 0349, 0370, 0418, 0283, 0401, 1037, 2089, 2090, 2092, 2093, 2197
Imperial Crown	0001, 0003, 0264, 0374, 0391, 0412, 0634
Indesit	0213
Indiana	0037
Infinity	0054
InFocus	0736, 1379, 1206, 1430, 1747
Ingelen	0163, 0487, 0610, 0714
Ingersol	0003
Initial	2417, 1990
Inkel	0571
Inno Hit	0003, 0072, 0076, 0102, 0217, 0218, 0247, 0282, 0307, 0516, 0517, 1037, 1149, 1580
Innova	0037
Innovation	0068, 1037
Innowert	0865, 1298
Inotech	0773, 0820
Insignia	0171, 0463, 1037, 1204, 1326, 1104, 1517, 1564, 1660, 1710, 1944, 2002, 2417, 2751
Inspira	1046
Inteq	0017
Interbuy	0003, 0037, 0068, 0247, 0264
Interfunk	0012, 0037, 0087, 0109, 0163, 0247, 0349, 0361, 0512, 0568
Internal	1454, 0451, 1909
Intervision	0003, 0037, 0068, 0102, 0217, 0218, 0247, 0264, 0282, 0377, 0394, 0414, 0283, 0039, 0455, 0464, 0486, 0487, 1037, 0654
iPure	1376, 1694
iRIS	2189
Irradio	0003, 0037, 0076, 0218, 0247, 0371, 0724, 2021
IRT	0451, 0180, 0706
Isukai	0037, 0218, 0282, 0455
ITC	0217, 0320
ITS	0037, 0216, 0218, 0264, 0282, 0371
ITT	0163, 0179, 0208, 0283, 0346, 0349, 0356, 0361, 0473, 0480, 0544, 0548, 0610, 1166, 1523, 1871, 1295, 0898, 2353, 2399, 2675, 1149, 2715
ITT Nokia	0163, 0179, 0180, 0208, 0346, 0349, 0361, 0356, 0283, 0473, 0480, 0548, 0606, 0610
ITV	0037, 0247, 0264, 0284, 0374
iView	2842
IX	0877

Janeil	0046
JBL	0054
JCB	0000
JCM	2189, 2256
JDV	1506
Jean	0003, 0036, 0051, 0092, 0156, 0179, 0236, 0474, 0721, 1511, 1513
JEC	0765
Jensen	0050, 0761, 0150, 1299, 1326, 1037
JGC	1677, 1709
Jiahua	0051
JiaLiCai	0003, 0264, 0412, 0646
Jinfeng	0051, 0208, 0226, 0150
Jinhai	0768, 1910
Jinque	0003, 0264, 0412, 0150
Jinta	0003, 0264, 0412, 0768, 1910
Jinxing	0003, 0037, 0054, 1145, 0156, 0264, 1454, 0706, 0150, 0765, 0768, 1006, 1037, 1013, 1044, 1355
JMB	0443, 0499, 1454, 0634, 2059
JNC	0876, 0896, 1536, 1626, 1964
JNL	1195
Jocel	0712
John Lewis	2451
Jouge	1435
JTV	0795, 0748
Jubilee	1454
Juhua	0264, 0412, 0150
JVC	0005, 0036, 0053, 0069, 0093, 0160, 0169, 0190, 0192, 0218, 0371, 0418, 0463, 0765, 0606, 0650, 0653, 0683, 0731, 1352, 1231, 1818, 1923, 2321, 2322, 2518
Kaige	0003, 0264, 0412, 0150
Kaisui	0003, 0037, 0216, 0217, 0218, 0282, 0455
Kambrook	0217, 0377, 0283
Kamp	0216
Kangchong	0768, 1910
Kanghua	0896
Kangli	0001, 0003, 0264, 0374, 0391, 0634, 0150
Kangyi	0003, 0264, 0412
Kaon	2353
Kapsch	0163, 0206, 0361
Karcher	0102, 0264, 0282, 0314, 0370, 0421, 0606, 0610, 0714, 0778, 0499, 1324, 1046, 1506, 0898
Kathrein	1454, 0880
Kawa	0371
Kawasho	0158, 0216, 0308
Kaypani	0052
KB Aristocrat	0163
KDS	0835
KEC	0180
Ken Brown	0236, 0463, 0455
Kendo	0037, 0102, 0235, 0247, 0294, 0362, 0370, 0377, 0411, 0610, 0648, 1037, 0640, 1149, 1437, 1580
Kenia	0019, 0030, 0082
Kenmark	2043
Kennedy	0163, 0206, 0213
Kennex	1037
Kenstar	2009, 1358, 1359
Kenwood	0019, 0030
Keydo	1626
Keymat	1326, 0765, 1504, 1570, 1771, 1888, 1358, 1890, 1359, 1895, 2035
Khind	0634, 0706, 0896
KIC	0217, 0329
King Bright	2471

Kingsley	0216
Kiota	0001, 0371, 0455
Kioto	0054, 1454, 0180, 0706, 0779
Kiss	0800
Kiton	0037, 0668
KLH	0765, 1962
KLL	0037
Kloss	0024, 0046
KMDS	2278
Kneissel	0037, 0238, 0292, 0362, 0370, 0374, 0411, 0499, 1454, 0610, 1624
Kobra	1298
Koenig	0012, 0037, 0101
Kolin	0033, 0036, 0037, 0053, 0150, 0180, 0474, 0748, 0889, 0178, 1610, 0755, 1666, 2287, 2290, 2361
Kolster	0037, 0102, 0218, 0247, 0349
Kongque	0003, 0264, 0646, 0150
Konichi	0003
Konka	0003, 0037, 0068, 0218, 0282, 0371, 0418, 0587, 0180, 0632, 0638, 0641, 0703, 0707, 0714, 0726, 0748, 0754, 0779, 0795, 0816, 0150, 0894, 1006, 1084, 1085, 1086, 1087, 1094, 1095, 1103, 1104, 1105, 1106, 1110, 1111, 0765, 1831, 1939, 1956, 2738
Kontakt	0487
Korpel	0037
Korting	0039, 0087, 0288, 0320, 0370, 0421
Koryo	1421, 1881
Kosmos	0037
Kost	1262, 0898
Kotron	0412, 1900
Koyoda	0003
Kraking	0238
Kreisen	0876, 1046
Kriesler	0012
Kross	1536
KTV	0030, 0039, 0180, 0183, 0185, 0217, 0280
Kuaile	0003, 0264, 0412
Kuba	0349
Kulun	0003
Kunlun	0051, 0208, 0226, 0264, 0374, 0634, 0150
Kuro	0373
Kyoshu	0039, 0412, 0418
Kyoto	0039, 0163, 0216, 0217
L&S Electronic	0714, 0808, 0865, 1949
Lark	0039
LaSAT	0486
Lava	1046, 0898
Lavic	1363
Lavis	1037
Leader	0003
Lecson	0037
Legend	0003, 0337
Lemair	0039, 0411
Lenco	0037, 0374, 0474, 0585, 0587, 0721, 1037, 1634, 1787, 1983, 2090, 2857
Lenoir	0003, 1189
Lenoxx	1189
Lentec	1531, 1696
Lenuss	2885
Lesa	0247
Level	2023, 2061
Lexsor	1196, 1507
Leyco	0037, 0072, 0264, 0294
LG	0001, 0003, 0004, 0017, 0019, 0030, 0037, 0038,

	0039, 0056, 0060, 0150, 0109, 0163, 0178, 0216,
	0217, 0247, 0361, 0370, 0377, 0283, 0442, 0474,
	1454, 0706, 0714, 0715, 0823, 0829, 0856, 1191,
	1046, 0898, 0499, 0047, 1318, 1681, 1718, 1768,
	1926, 1934, 1295, 2359, 3042
Liesenkoetter	0012, 0037
Lifetec	0003, 0037, 0218, 0374, 0668, 0683, 0714, 1037,
	0640, 2001
Lihua	0150
LiteOn	1088
Lloyd	2399
Lloyd's	0001, 0003, 1904
Lloytron	0039
LME	0283
Local Calcutta TV	1239, 0499
Local Chennai TV	0003, 1239, 1411, 1421, 1422
Local Delhi TV	1239, 1473
Local India TV	0003, 0158, 0208, 0264, 0371, 0602, 1009, 1046,
	1239, 1411, 1359, 0499, 1421, 0765, 1473
Local Malaysia TV	0706, 1203
Lodos	1037, 1149
Loewe	0037, 0087, 0136, 0292, 0370, 0512, 0516, 0633,
	0655, 0790, 1884, 2216
Logic	2107
Logik	0001, 0005, 0003, 0011, 0016, 0033, 0060, 0371,
	0706, 0773, 0880, 1037, 0889, 1471, 0835, 1795,
	1727, 2028, 1831, 2030, 1486, 2107
Logix	1037, 0668
Longjiang	0264, 0412, 0150
Luce	0813, 1031
Luker	1506, 1985
Luma	0003, 0163, 0206, 0305, 0362, 0356, 0374, 0411,
	1037
Lumatron	0037, 0073, 0163, 0206, 0217, 0264, 0305, 0356,
	1827, 2023, 2471
Lux May	0003, 0037
Luxman	0056
Luxor	0163, 0179, 0194, 0208, 0217, 0346, 0349, 0356,
	0361, 0384, 0401, 0473, 0480, 0548, 0631, 1037,
	1149
LXI	0047, 0054, 0154, 0156, 0178, 0747
Lynx	0773
M Electronic	0003, 0037, 0068, 0105, 0109, 0163, 0195, 0216,
	0217, 0247, 0287, 0343, 0346, 0349, 0361, 0374,
	0411, 0480, 0512, 0634, 0714, 1652
M&S	0054, 0236
Madison	0037
MAG	0835
Magnadyne	0087, 0102, 0163, 0247, 0307, 0516, 0544
Magnafon	0073, 0076, 0102, 0213, 0216, 0307, 0314, 0516
Magnasonic	1326, 1904, 1928
Magnavox	0011, 0020, 0024, 0028, 0030, 0765, 0036, 0051,
	0054, 0096, 0171, 0179, 0186, 0187, 0230, 0039,
	0706, 0729, 0753, 0748, 0802, 0499, 1069, 1154,
	1198, 1203, 1365, 1454, 1506, 1525, 1543, 0755,
	1867, 1904, 1931, 1944, 1990, 2597, 2655, 2879,
	2902
Magnin	1907
Magnum	0037, 0648, 0714, 0715, 1166, 1289, 1046, 2023
Majestic	0015, 0016
Malata	1795
Mandor	0264
Manesth	0765, 0037, 0217, 0235, 0264, 0294, 0320
Manhattan	0037, 0668, 0778, 0876, 1037, 2051, 1367, 1046
Manta	1677

Maqma	1298, 1606, 1626, 1789
Marantz	0030, 0037, 0054, 0412, 1367, 0854, 1154, 1398, 1454, 1532, 1714
Marelli	0087
Mark	0003, 0037, 0216, 0217, 0374, 0714, 0715
Marks and Spencer	1770, 1847, 2673
Marquant	2056
Maruman	0391, 0627
Mascom	1046, 1871
Mastec	1997
Master	0753
Master's	0499
Mastro	0053, 0706, 0748, 1046, 1558
Masuda	0003, 0037, 0217, 0218, 0264, 0371
Materin	0858
Matrix	0888
Matsui	0003, 0011, 0033, 0765, 0036, 0037, 0072, 0177, 0195, 0208, 0211, 0217, 0235, 0272, 0294, 0335, 0349, 0440, 0355, 0356, 0371, 0283, 0443, 0449, 0455, 0487, 0516, 0401, 0544, 1454, 0714, 0744, 0880, 1037, 1471, 1666, 1149, 1916, 1670, 1581, 1831, 2090, 1506, 2486, 2393
Matsushita	0051, 0161, 0250, 0650
Matsuviana	0587
Maxdorf	0773, 1196, 1572
Maxent	0755, 1211, 1714, 1757
Maxess	2493
Maxim	1166, 1046, 1506
Maxivideo	0314
Maxwel	1475
MB Quart	1727
MCE	0003
McMichael	0043
McTronics	1662
ME	1046
Mecer	2011
Meck	0706, 0748, 1558, 1006
Medialine	1206, 1964
MediaLink	1728
Mediator	0012, 0037, 1454
MediaVision	1391
Medion	0037, 0245, 0512, 1454, 0668, 0706, 0714, 0808, 0880, 1037, 0640, 1149, 1166, 1248, 1437, 1046, 1580, 0835, 1900, 2001, 1506, 2165, 1849, 3049 1248
MegaDrive	1248
Megapower	0003
Megas	0610
Megatron	0003, 1145, 0178
MEI	0185, 1037
Meile	0264, 0412, 0150, 0768, 1910
Melvox	0215, 0400
Memorex	0003, 0016, 0056, 0060, 0150, 0154, 0178, 0179, 0250, 0463, 0877, 1037, 1570, 0171, 1670, 1710, 1911, 1920, 1924, 1926, 1927, 1938, 1985, 2739 1983
Memory	1983
Memphis	0003, 0072, 0337
Mercury	0001, 0003, 0037, 0060, 0329
Mermaid	0037
Metronic	0625
Metz	0037, 0087, 0195, 0213, 0367, 0388, 0447, 0535, 0587, 0668, 0746, 1149, 1533
MGA	0019, 0030, 0150, 0155, 0178, 0218, 0374, 1907
Micro	1046
Micromaxx	0037, 0668, 0714, 0808, 1037, 1324, 2001
Microspot	1614

Microstar	0808
Microtek	0820, 0748
Midland	0017, 0039, 0047, 0051, 0135, 0747
Mikomi	0744, 1037, 1149, 0499, 2055
Minato	0037
Minerva	0070, 0076, 0150, 0195, 0307, 0487, 0516, 0535, 1248
Ministry Of Sound	1149
Minoka	0037, 0412
Mintek	2417, 1990
Minutz	0021
Mirai	1666, 1852, 2028
Mirror	1900
Mitsai	1046
Mitsubishi	0014, 0019, 0030, 0033, 0036, 0037, 0056, 0087, 0093, 0098, 0150, 0154, 0155, 0178, 0179, 0180, 0201, 0236, 0250, 0331, 0440, 0382, 0474, 0512, 0535, 1454, 0592, 0868, 1037, 1182, 1250, 1350, 1797, 0818, 2294, 2313
Mitsumaru	0004
Mivar	0076, 0216, 0217, 0291, 0292, 0307, 0516, 0517, 0609, 2386
Mogen	1683, 1820
Monaco	0003
Monde Vue	2071
Monivision	0003, 0843
Monix	0748
Moree	0037
Morgan's	0037
Moserbaer	1149, 1421, 1580, 0876, 0896
Motion	0076
Motorola	0093, 0835
Moxell	0835
mp man	1849
MTC	0019, 0030, 0056, 0060, 0091, 0185, 0216, 0349, 0370, 0512
MTEC	0039, 0272
MTlogic	0714, 2050, 2059
MTR	0247
Mudan	0003, 0051, 0208, 0226, 0264, 0412, 0150
Multimat	0314
Multistandard	0102, 0314
Multitec	0037, 0486, 0668, 1037, 1046
Multitech	0003, 0037, 0516, 0076, 0102, 0180, 0216, 0217, 0247, 0264, 0314, 0356, 0370, 0486
Murphy	0039, 0163, 0204, 0216, 0474, 0443
Musikland	0218, 0247
MVM	3117
Mx Onda	0835, 1820, 1983, 2021
MyCom	1376
Myrica	1666
Myryad	1454
NAD	0037, 0056, 0156, 0178, 0361, 0865, 0866, 1166
Naiko	0037, 0606, 0753, 0003, 1932, 1942, 1506
Nakamichi	1493
Nakimura	0037, 0374
Nanbao	0003, 0264, 0412, 0768, 1910
Nansheng	0264, 0412, 0150
Naonis	0356
Narita	1506
NAT	0226
National	0051, 0208, 0226, 0044, 0240, 0449, 0765, 2300
Naxa	1998, 2059, 2735
NEC	0003, 0011, 0019, 0030, 0036, 0046, 0051, 0053, 0056, 0154, 0156, 0165, 0170, 0178, 0186, 0217,

	0245,	0264,	0320,	0374,	0412,	0455,	0474,	0499,
	0765,	0653,	0634,	0150,	0876,	1367,	1370,	1398,
	0898,	1546,	1797,	1852,	0877,	2186,	2188,	2461
Neckermann	0010,	0037,	0087,	0195,	0203,	0213,	0247,	0320,
	0349,	0356,	0370,	0411,	0418,	1454		
NEI	0037,	0337,	0371,	0283,	1037			
Nelco	1044							
NEO	0754,	0894,	1324					
Neoka	1592,	1826						
Neon	2051,	1614,	2673					
Neovia	0865,	0876,	1206,	1318,	1338,	1191,	1373,	1376,
	1382,	1384,	1387,	0499,	1710,	1964		
Nesco	0179,	0247,	0414,	0604				
Nesx	1614							
Netsat	0037							
NetTV	0755,	1381						
Netway	1578							
Network	0039,	0337						
Neufunk	0003,	0037,	0218,	1454,	0585,	0610,	0714,	0697
New Tech	0003,	0037,	0217,	0343,	0039,	1454		
New World	0218							
Newave	0003,	0092,	0093,	0161,	0178,	0721,	0150	
NewSonic	1826							
NEX	0753							
Next Base	2064							
Nextier	1598							
Nexus Electronics	0178							
NFREN	0800							
Nicam	0544							
Nicamagic	0216							
Nikai	1149							
Nikkai	0003,	0039,	0765,	0036,	0037,	0072,	0216,	0217,
	0218,	0264,	0337,	1677				
Nikkei	0714,	1594,	2059,	2172				
Nikko	0030,	0092,	0178,	0039				
Niko	1581							
Nikon	0768,	1910						
Nimbro	2059							
Nintaus	0748							
Nippon	1239							
Nisato	0391							
Nissan	2336							
Noblex	0018,	0052,	0154,	0264,	0430,	0482		
Nobliko	0070,	0076,	0102,	0216,	0314			
Nogamatic	0109,	0196,	0333,	0103,	0568			
Nokia	0163,	0179,	0180,	0208,	0320,	0346,	0349,	0356,
	0361,	0374,	0473,	0480,	0548,	0606,	0610,	0631,
	0861							
Norcent	0748,	2295,	1089,	1365,	1589,	1590,	1581,	1745
Nordic	0217							
Nordmende	0037,	0085,	0103,	0109,	0195,	0196,	0213,	0287,
	0304,	0343,	0560,	0568,	0714,	0748,	1149,	1289,
	0499,	1359,	1580,	1793,	0625,	2001,	0443,	2107
Normerel	0037							
Nortek	0668							
Northern Star	1206							
Norwood Micro	1381,	0802						
Noshi	0018							
Novak	0012							
Novatronic	0037,	0105,	0374,	1037				
Novex	1523							
Novita	1384,	1580						
NPC	1024							
NTC	0092							
Nu-Tec	0455,	0706,	0820,	0765,	2197			

NuVision	1657, 2158
O.K.Line	1037, 1324
Oceanic	0163, 0208, 0215, 0361, 0356, 0400, 0401, 0473, 0548
Odeon	0264, 1795
Odys	1795, 2165, 2389, 2799, 2922, 2923, 3026
Okano	0003, 0037, 0072, 0264, 0370, 2982
OKI	0898, 2200
Okishi	1544
Olevia	1144, 0178, 1365, 1610, 1813
Olidata	1376
Olin	2808
Omega	0264
Omni	0706, 0748, 0872, 1570
OnCommand	1037
One	1517
Onei	1149
Onida	0053, 0653, 1046, 1231, 2333, 2396, 2533, 2831
Onimax	0714
Onix	0706
Onking	0280
Onn	1149, 1709, 1770, 1831, 2055, 2062, 0898, 2130, 2133, 2166, 2242, 1506, 3024
Onwa	0102, 0180, 0218, 0371, 0602
Onyx	1709, 1770
Opera	0037, 0714, 0499, 1770, 2032
Optimus	0154, 0166, 0250, 0650, 1904, 1924, 1927
Optiview	0756
Optoma	0887, 1348, 2162
Optonica	0093, 0165
Orbit	0037, 1696
Orcom	1504
Orion	0011, 0037, 0102, 0177, 0179, 0211, 0235, 0236, 0264, 0294, 0039, 0320, 0355, 0412, 0443, 0463, 0474, 0516, 0544, 1454, 0655, 0714, 0880, 1037, 1196, 1905, 1908, 1911, 1915, 1916, 1929, 1938, 1670, 2001, 1696, 2032, 2108
Orline	0037, 0218
Ormond	0668, 1037
Orson	1438
Orsowe	0516
Osaki	0039, 0037, 0072, 0211, 0217, 0218, 0264, 0272, 0355, 0374, 0412, 0474, 1454
Oscar	1473
Osio	0037
Oso	0218
Osume	0039, 0036, 0037, 0072, 0218, 0474
Otake	0039
Otic	1006, 1203, 1326, 0835, 1983
Otto Versand	0010, 0036, 0037, 0093, 0109, 0195, 0213, 0217, 0226, 0235, 0247, 0294, 0320, 0336, 0343, 0349, 0361, 0512, 0535, 0544, 1454
OVP	1580
Pacific	0443, 1454, 0714, 1037, 0640, 1324, 2060, 2126
Packard Bell	0092, 0898, 1046
Pael	0216
Palladine	1504, 2081
Palladium	0010, 0037, 0087, 0163, 0195, 0213, 0217, 0247, 0349, 0356, 0370, 0411, 0418, 1037, 1454, 0655, 0714, 0640, 1506
Palsonic	0001, 0037, 0217, 0218, 0264, 0284, 0377, 0418, 0039, 0706, 0773, 0778, 0779, 1183, 1196, 1326, 1507, 1538, 1572, 1705, 1795, 1813, 1904, 1769, 2410, 2461, 1849, 1531
Panama	0003, 0037, 0216, 0217, 0247, 0264

Panashiba	0001							
Panasonic	0037, 0051, 0054, 0100, 0150, 0161, 0162, 0163, 0208, 0213, 0226, 0044, 0240, 0250, 0356, 0361, 0367, 0375, 0462, 0765, 0516, 0548, 0650, 0853, 0896, 1290, 1310, 1636, 1919, 1924, 1927, 1946, 1947, 2300, 2519							
Panavision	0037, 0411							
Panavox	0861							
Panda	0003, 0051, 0208, 0226, 0264, 0412, 0765, 0646, 0706, 0748, 0150, 0768, 1044, 1843, 1910							
PARK	1376, 2059, 2194, 2202							
Pathe Cinema	0163, 0213, 0215, 0216, 0238, 0292, 0320, 0400, 0283							
Pathe Marconi	0109, 0196, 0213, 0333, 0103, 0568							
Pausa	0003							
PDI	1046							
Peng Sheng	0748							
Penney	0001, 0003, 0018, 0019, 0021, 0027, 0030, 0039, 0047, 0051, 0056, 0060, 0110, 0135, 0149, 0156, 0178, 0309, 0747, 1347, 1907, 1919, 1926							
Perdio	0037, 0072, 0163, 0209, 0216, 0282, 0320							
Perfekt	0037							
Performance Technique	1186, 1187							
Pershin	0400							
Petters	0037, 1523							
Phase	0039							
Philco	0019, 0020, 0024, 0028, 0030, 0039, 0037, 0054, 0056, 0068, 0074, 0076, 0082, 0087, 0092, 0096, 1145, 0163, 0171, 0178, 0179, 0180, 0186, 0187, 0213, 0247, 0370, 0036, 0391, 0418, 0451, 0463, 0474, 0747, 0774, 0786, 1624, 1911, 1944							
Philex	0356							
Philharmonic	0217							
Philips	0000, 0003, 0012, 0013, 0017, 0019, 0020, 0024, 0027, 0028, 0030, 0039, 0037, 0043, 0051, 0054, 0056, 0087, 0092, 0150, 0171, 0178, 0186, 0187, 0230, 0238, 0293, 0323, 0332, 0343, 0361, 0374, 0474, 0512, 0195, 0585, 0638, 0721, 0747, 0774, 0892, 0047, 0499, 1154, 1454, 0898, 1506, 1521, 0755, 1756, 1815, 1850, 1867, 2227, 2301, 2597, 2622, 2665, 2720, 2822, 2852, 2992							
Phocus	0714, 1289, 0499, 1652							
Phoenix	0037, 0072, 0087, 0163, 0216, 0320, 0370, 0486							
Phonola	0012, 0013, 0037, 0087, 0216, 0293, 1454							
Phonotrend	1594							
PHOS Italy	1843							
Pilot	0019, 0030, 0039, 0706, 0712							
Pioneer	0011, 0037, 0038, 0109, 0163, 0166, 0170, 0172, 0287, 0361, 0370, 0486, 0512, 0679, 0706, 0760, 0866, 0892, 1398, 1636, 0748, 1717, 2045, 2458							
Pionier	0370, 0486, 1046							
Planar	1288, 1496, 1589, 3019							
Plantron	0003, 0037, 0264							
Play	2051							
Playsonic	0037, 0217, 0208, 0714, 0715, 1652							
Plus	1143							
Plustron	1770, 2021							
Polaroid	0765, 0865, 1262, 1196, 1381, 0898, 1316, 1326, 1032, 1282, 0499, 1104, 0835, 1523, 1538, 0773, 1720, 1762, 1766, 1767, 1769, 1826, 1962, 2002, 1831, 2063, 1694, 2120							
Policom	0109, 0568							
Polytron	0282, 0697							
Polyvision	0889, 1144							
Poppy	0003							

Portland	0019, 0039, 0092, 0374, 0451
Powerpoint	0037, 0487, 0706, 0894, 1770, 1802
Prandoni-Prince	0076, 0213, 0247, 0307, 0361, 0356, 0516
Precision	0217, 1792
Premier	0003, 0264, 0004, 0748, 1195, 0753, 0284
President	0748
Prima	0003, 0039, 0068, 0264, 0412, 0474, 0753, 0761, 1037, 0150, 1196, 1507, 0178, 1710
PrimeView	1606
Princess	0773, 1326
Princeton	0685, 0003, 0717
Prinston	0715, 1037
Prinz	0072, 0194, 0349, 0361, 0544
Prism	0051
Profex	0003, 0076, 0163, 0361, 0356
Profi	0003
Profilo	1046
Profitronic	0037, 0102, 0314
Projectiondesign	1725, 1750, 1752
Proline	0012, 0037, 0072, 0411, 0625, 0634, 1037, 1376, 1513, 1545, 1613, 1727, 2059, 1709
Promac	2682
Proscan	0030, 0047, 0466, 0747, 1347, 1922, 2147, 0178, 2256
Proscop	0156
Prosonic	0037, 0209, 0216, 0217, 0370, 0371, 0374, 0606, 0668, 0714, 0880, 1166, 1196, 0499, 0898, 1324, 1376, 1507, 1545, 1149, 1709, 1614, 1739, 1770, 0876, 1787, 1820, 1849, 1727, 1890, 2001, 2021, 1696, 2050, 2085, 2090, 2032, 2139, 2197, 0156, 2062, 1845, 1037, 2059
Protech	0003, 0037, 0102, 0217, 0247, 0264, 0282, 0337, 0349, 0418, 0283, 0486, 0668, 1037
Protek	2336
Proton	0001, 0003, 0030, 0031, 0039, 0052, 0056, 0149, 0178, 0466, 0474, 0060, 1546, 1874
Protron	1320, 1323
Proview	0835
ProVision	0037, 1454, 0714, 1324, 1531
Proxima	0376, 1145, 0742, 0758, 1430, 1747
Pulsar	0017, 0019
Puneet	1546
Punktal	2687
Pvision	0876, 1191, 0178, 1222, 1521, 2001
Pye	0012, 0013, 0037, 0087, 0293, 0349, 0374, 0412, 0195, 1454, 2456
Pyle	1200, 2062, 2093
Pymi	0003
Q.Media	2799
Qingdao	0051, 0208, 0226, 0264, 0412, 0150
QONIX	1594, 1634
Quadra Vision	0215, 0400
Quadral	0218
Quadro	0753, 0796, 1149, 1326, 2107
Qualcraft	0039
Quasar	0003, 0051, 0165, 0219, 0247, 0250, 0474, 0650, 0865, 1919, 1924, 1927
Quelle	0010, 0011, 0039, 0037, 0070, 0074, 0109, 0195, 0203, 0213, 0247, 0295, 0349, 0361, 0512, 0535, 0544, 0668, 1037
Questa	0039, 0036
R-Line	0037
Radialva	0163, 0218, 0337, 0283
Radiola	0012, 0037, 0217, 0323, 1454
Radiomarelli	0037, 0087, 0201, 0247, 0307, 0516

RadioShack	0019, 0030, 0037, 0039, 0047, 0056, 0154, 0165, 0178, 0180, 0747, 1827, 1904, 1920
Radiotone	0003, 0037, 0264, 0295, 0370, 0412, 0418, 0601, 0648, 0668, 1037
Rafena	0297
Rank	0070
Rank Arena	0036, 0602, 0753, 0796, 1764
Ranser	0001
RBM	0070, 0089
RCA	0000, 0018, 0019, 0029, 0030, 0038, 0047, 0051, 0060, 0090, 0092, 0093, 0135, 0178, 0254, 0333, 0560, 2051, 0451, 0625, 0679, 0747, 0753, 0774, 0796, 0825, 1347, 1454, 1907, 0818, 1919, 1922, 1948, 1958, 1959, 2002, 2323, 2403, 2256, 2932
Realistic	0019, 0030, 0039, 0056, 0154, 0165, 0178, 0180
RealTV	2051
Reality	2051
Recco	0706
Recor	0037, 0418
Record	0230
Rectiligne	0037
Rediffusion	0036, 0201, 0346, 0356, 0361, 0548
Redstar	0037
Reel Multimedia	1424
Reflex	0037, 0668, 1037
Relisys	0865, 0876, 0877, 0878, 1206, 1207, 1209, 1211, 1376, 1521, 1580, 1598, 1612, 0835, 1739, 1740
Relon	1826
Remotec	0037, 0093, 1145, 0171, 0250, 0376, 0391, 0627
Render	2062
Reoc	0714
RevolutionHD	1623
Revox	0037, 0808
Rex	0163, 0206, 0247, 0264, 0286, 0305, 0356, 0411
RFT	0037, 0072, 0087, 0264, 0297
Rhapsody	0183, 0185, 0216
Rinex	0773
Roadstar	0003, 0037, 0218, 0264, 0282, 0418, 0668, 0714, 0715, 1037, 1189, 1900, 2069, 1820, 2308
Roberts	0406
Robotron	0087
Rolson	0819, 1191, 2098
Rosen	0756
Rover	0036, 0877
Rowa	0003, 0037, 0216, 0264, 0587, 0706, 0712, 0748, 0150, 0898, 1006, 1046, 1421, 0765, 0047
Roxy	0039
Royal	0825
Royal Lux	0335, 0370, 0412, 0421
Runco	0017, 0030, 0612, 1398, 1717
Ruyi	0044, 0150
S-Media	0889
Saba	0087, 0103, 0109, 0163, 0196, 0213, 0250, 0287, 0304, 0307, 0335, 0343, 0361, 0471, 0498, 0516, 0548, 0560, 0568, 0625, 0714, 1166, 1365
Saccs	0238
Sagem	0455, 0610, 2051, 0830, 1313, 1596
Saige	0003, 0150
SailorPlus	0802
Saisho	0003, 0011, 0033, 0163, 0177, 0211, 0217, 0235, 0264, 0440, 0283, 0516, 0544, 1581
Saivod	0037, 0668, 0712, 1037, 1149, 1046, 1506, 1770
Sakai	0163
Sakura	1203, 1326
Sakyno	0455

Salora	0163,	0194,	0208,	0349,	0356,	0361,	0365,	0461,
	0480,	0516,	0548,	0631,	1166,	1402,	0804,	0672,
	1046,	0898,	2154,	2197,	2165,	2353		
Salsa	0335							
Sambers	0076,	0102,	0213,	0307,	0314,	0516,	0517	
Sampo	0003,	0030,	0036,	0039,	0052,	0092,	0093,	0100,
	0110,	0154,	0171,	0178,	0474,	0650,	0721,	0755,
	0898,	1104,	1581,	2238,	2310			
Samsung	0003,	0019,	0030,	0037,	0039,	0056,	0060,	0072,
	0090,	0092,	0093,	0110,	0154,	0156,	0163,	0178,
	0179,	0208,	0216,	0217,	0226,	0264,	0329,	0370,
	0427,	0474,	0482,	0517,	1037,	1454,	0587,	0650,
	0765,	0747,	0766,	0774,	0814,	0150,	1575,	0755,
	1581,	1907,	1959,	0748,	2051,	2220,	2557,	2783
Samsux	0039							
Sandra	0216,	0217,	0307					
Sanjian	0264,	0412						
Sanken	1507,	0748						
Sansei	0092,	0451						
Sansui	0037,	0165,	0171,	0173,	0371,	0455,	0463,	0602,
	0655,	0706,	0714,	0727,	0729,	0753,	0861,	0888,
	0898,	1236,	0765,	1248,	1358,	1191,	1409,	1359,
	1531,	1537,	1545,	1046,	1594,	1670,	1682,	1697,
	1626,	1703,	1727,	1904,	1911,	1929,	1938,	2001,
	2847,	2900						
Santon	0003							
Sanyo	0003,	0011,	0036,	0054,	0068,	0072,	0088,	0150,
	1145,	0146,	0154,	0156,	0159,	0163,	0170,	0180,
	0208,	0213,	0216,	0217,	0044,	0232,	0264,	0280,
	0292,	0297,	0370,	0373,	0376,	0412,	0474,	0484,
	0765,	0544,	0585,	1367,	0721,	0798,	1037,	1154,
	1179,	1196,	1507,	1580,	1365,	1624,	1649,	1149,
	1907,	1975,	2115,	0761,	2236,	2237,	2238,	1506,
	2455,	2461,	2600,	1589,	2875,	1831,	3008,	3013,
	3032,	3039						
Sanyuan	0003,	0093,	0150					
SBR	0012,	0013,	0037,	0043,	1454			
Sceptre	0878,	0889,	1360,	1599,	0867,	2506		
Schaub Lorenz	0349,	0361,	0374,	0486,	0548,	0606,	0714,	0878,
	1191,	2051,	0499,	1324,	1363,	1149,	1964,	2001,
	2032,	0898,	2059,	2172,	2200			
Schauen	2404							
Schneider	0012,	0013,	0037,	0070,	0163,	0217,	0218,	0247,
	0323,	0336,	0343,	0349,	0352,	0361,	0371,	0394,
	0544,	1454,	0648,	0668,	0714,	1037,	0640,	1324,
	1046,	1617,	1904,	1908,	1506,	3024		
Schoentech	1037							
Scimitsu	0019							
Scotch	0178							
Scotland	0163							
Scott	0019,	0178,	0179,	0180,	0236,	0309,	1189,	1677,
	1711,	1983						
Sears	0015,	0047,	0054,	0056,	0146,	0149,	0154,	0156,
	0159,	0168,	0171,	0178,	0179,	0039,	0747,	1007,
	1904,	1926						
Seaway	0634							
Seelver	1037							
SEG	0003,	0036,	0037,	0076,	0102,	0216,	0217,	0218,
	0247,	0264,	0297,	0314,	0349,	0362,	0414,	0487,
	0451,	0668,	1037,	1149,	1437,	1901,	2061,	0898,
	2165,	2673						
SEI	0010,	0037,	0087,	0102,	0163,	0177,	0206,	0213,
	0294,	0314,	0349,	0516,	0544			
Sei-Sinudyne	0010,	0037,	0087,	0102,	0206,	0213,	0294,	0314,
	0516,	0544						

Seitech	1324
Seleco	0163, 0206, 0286, 0305, 0346, 0362, 0356, 0371, 0411, 0673, 1145, 1297
Semivox	0180, 0236, 0463
Semp	0156, 0765
Sencora	0003
Sense	1845, 1847, 1727
Sensei	1626
Sentra	0765, 0283
Serie Dorada	0001, 0019, 0030, 0056, 0156, 0178, 0180
Serino	0093, 0216, 0455, 0610
SeViC	1705
Shancha	0264, 0412, 0150
Shanghai	0003, 0208, 0226, 0264, 0329, 0412, 0150, 0768, 1910
Shaofeng	1145, 0044, 0150
Sharp	0003, 0030, 0036, 0039, 0053, 0093, 0153, 0165, 0256, 0294, 0440, 0474, 0491, 0516, 0650, 0653, 0720, 0818, 0854, 2099, 1589, 2495
Sharper Image	1950
Shen Ying	0003, 0092, 0179, 0474
Shencai	0003, 1145, 0264, 0412
Sheng Chia	0003, 0033, 0093, 0179, 0236, 0474, 0150
Shenyang	0003, 0264, 0696, 0753, 0150
Sherwood	0003, 1399, 0876
Shinco	1990, 3093
Shinelco	1358, 2059
Shintoshi	0037
Shivaki	0037, 0178, 0443, 2107
Shogun	0019
Shorai	0179, 0294
Show	0003, 0072, 0418
Siam	0037
Siarem	0087, 0102, 0163, 0213, 0307, 0516
Siemens	0039, 0037, 0146, 0036, 0195, 0203, 0213, 0535, 2421
Siera	0012, 0037, 1454
Siesta	0370
Signal	1145, 1569, 1910
Signature	0016, 0054
Signet	0800, 0844, 1262
Silva	0037, 0216, 0361, 0648
Silva Schneider	0037, 0648, 0801, 1166, 1046, 1506, 0898, 2166
Silvano	0587
Silver	0036, 0179, 0361, 0455, 0715
SilverCrest	1037
SIM2 Multimedia	0673, 1297
SIMA	0673
Simpson	0186, 0187
Simz	1820
Singer	0003, 0087, 0102, 0215, 0247, 0335, 0371, 0400, 0748, 1537, 1046
Sinotec	0773, 1708
Sinudyne	0010, 0037, 0087, 0102, 0163, 0177, 0206, 0213, 0235, 0294, 0314, 0349, 0361, 0516, 0544, 1324
Skantic	0356
SKY	0037, 0282, 0880, 1376, 1504, 1511, 1513, 1606, 1612, 1613, 1614, 1615, 1745, 1709, 1778, 1848
SKY Brazil	0880
Skygiant	0180
Skysonic	0696, 0753, 0796
Skyworth	0003, 0037, 0264, 0696, 0706, 0727, 0748, 0753, 0796, 0805, 0150, 0825, 1115, 1117, 1118, 1119, 1123, 1006, 1130, 1131, 1133, 1134, 1138, 1140, 1061, 1799, 1589, 2862, 2961, 2973, 2975, 2999,

	3055, 3058, 3060, 3063
SL	1709
Sliding	0800, 0865, 0880, 1318, 1324, 0640, 1207, 1375, 1377, 1383, 0898
SLX	0668
Smaragd	0487
SmartVision	0894, 1183, 1843
Sodiff	2336
Soemtron	0865, 1298
Sogera	0320
Sogo	0606, 1376, 2050
Solarism	1220
Solavox	0039, 0037, 0072, 0163, 0356, 0361, 0548
Sole	1031, 1206, 1377, 0898, 1318, 1623, 2076
Sonawa	0218
Sonber	0102
Songba	0003
Sonic	0753
Soniko	0037
Soniq	1298, 1626, 2474, 2493, 2829
Sonitron	0208, 0217, 0370
Sonix	1376, 1614
Sonneclair	0037
Sonoko	0003, 0037, 0217, 0264, 0282
Sonolor	0010, 0163, 0208, 0215, 0282, 0361, 0400, 0401, 0548
Sontec	0003, 0037, 0294, 0370
Sontech	1983
Sony	0000, 0003, 0010, 0011, 0033, 0036, 0074, 0080, 0102, 0314, 0353, 0384, 0742, 0810, 0867, 1300, 1104, 1400, 1685, 1904, 1925, 2571, 2736
Sound & Vision	0102, 0218, 0374
Soundesign	0178, 0179, 0180, 0186
Soundwave	0039, 0037, 0320, 0418, 0715, 1037, 1770, 1847
Sova	1320, 1952
Sowa	0036, 0051, 0060, 0092, 0156, 0178, 0226, 0474, 0150
Soyea	0773, 0748
Soyo	1546, 1746, 1738, 0466, 1826, 1789, 1830, 1831
Space Tek	1696
Spectra	0003
Spectricon	0003, 0137
Spectroniq	0835
Squareview	0171
Ssangyong	0003, 0039
SSS	0019, 0180
Stag	0039
Staksonic	0003
Standard	0003, 0037, 0217, 0218, 0320, 0374, 1037, 1709, 2090
Starlite	0003, 0037, 0163, 0180, 0264
Starmedia	1578
Starvision	1184
Stenway	0218, 0282
Stern	0163, 0206, 0264, 0286, 0305, 0356, 0411
Strato	0003, 0037, 0264, 1787, 2032
Strong	0874, 1149
Studio Experience	0843
Stylandia	0217
SunBriteTV	1420, 1435, 0867
Sungoo	1248, 2037
Sunkai	0218, 0235, 0294, 0348, 0355, 0455, 0487, 0610, 0865
Sunny	0037, 1617
Sunstar	0003, 0037, 0264, 0371

Sunstech	2197, 1964, 2001, 1849
Sunwatt	0455
Sunwood	0037
Super	1189
Supercomp	0748
Superla	0216, 0217, 0516
Superscan	0093, 0864, 1944
Supersonic	0003, 0208, 0455, 0805, 1189, 0178, 2516, 2784
SuperTech	0003, 0037, 0216, 0218, 1454
Superton	0516
Supra	0003, 0039, 0056, 0178, 0374
Supratech	2206, 2208, 2210, 2211
Supre-Macy	0046
Supreme	0000
Susumu	0218, 0287, 0335, 0474
Sutron	0003
SVA	0587, 0748, 0768, 0865, 0871, 0872, 0047, 1326, 1421, 1944, 3066, 3071, 1046
Svasa	0208, 0455
Swedx	1606
Sweex	2062
Swissflex	2062
Swisstec	0865, 0880, 1376, 1504, 1511, 1513, 1606, 1612, 1613, 1614, 1615, 1745, 1709, 1778, 1848, 1849, 2059, 2061, 2062, 2165
Sydney	0216, 0217
Sylvania	0020, 0024, 0028, 0030, 0054, 0096, 0171, 0186, 0187, 0036, 0587, 0898, 1817, 1904, 1931, 1944, 2861
Symphonic	0068, 0171, 0180, 1904, 1944
Synco	0000, 0036, 0060, 0092, 0093, 0178, 0451, 0474, 0755, 1826
Syntax	1144, 0178, 1610
Sysline	0037
Sytong	0216
T+A	0447
Tacico	0003, 0092, 0178, 0179, 0474, 0150
Tactus	0272
Tahoci	0561
Tai Yi	0003, 0150
Taishan	0003, 0374, 0391, 0150
Talent	0178
Tandata	0439
Tandberg	0109, 0196, 0295, 0337, 0361, 0367
Tandy	0039, 0072, 0093, 0163, 0217, 0218, 0247, 0414
Targa	2051, 1191, 2062
Tashiko	0039, 0033, 0036, 0043, 0092, 0146, 0163, 0170, 0216, 0217, 0356, 0650, 0721, 0150
Tatung	0003, 0011, 0036, 0037, 0051, 0054, 0060, 0072, 0154, 0156, 0217, 0272, 0474, 0516, 0765, 0180, 1101, 0753, 0150, 1191, 1248, 0499, 1287, 1288, 1324, 1381, 1046, 0835, 2885, 1720, 1756, 1857, 2292, 2496, 2672
Tauras	2197, 3024
TCC	0706
TCL	0412, 0706, 0727, 0779, 0892, 0898, 1020, 1027, 1036, 1037, 1046, 1049, 1537, 1883, 1916, 2403, 2323, 2449, 0047, 2032, 2967, 3102
TCM	0714, 0808, 1289, 0499, 2001
Teac	0003, 0037, 0170, 0171, 0178, 0217, 0264, 0282, 0336, 0349, 0412, 0418, 0283, 0455, 0512, 0544, 0587, 0451, 0668, 0686, 0706, 0712, 0714, 0721, 0755, 0892, 0898, 1006, 1037, 1149, 1203, 1238, 1248, 1363, 1437, 1534, 1621, 0835, 1668, 1486, 1709, 1770, 1794, 1795, 1820, 1904, 1909, 1932,

	1949, 1983, 1985, 2032, 2168, 2471, 1769, 2761, 3084, 3158, 3163
Tec	0003, 0037, 0217, 0247, 0335, 0337, 0471, 0474
Tech Line	0037, 0668, 1149, 1437
Tech Lux	1189, 0748
Techica	0218
Technema	0320
Technica	1037, 1506
Technics	0051, 0250, 1454, 0650
Technika	1149, 1849, 1727, 1983, 1831, 2032, 2059, 0898, 2168, 2197, 2212
TechniSat	0297, 1454, 0640, 0655, 2051, 2090, 1166
Technisson	0714, 1289, 1652
Techno	1580, 2107, 1831
Technol Ace	0179
Technosonic	0499, 1454, 0625, 0880, 1324, 1326, 1890, 1506, 2032
Technotrend	1531, 1626, 2090
Techview	0847, 1261
Techvision	1709, 1771, 2032
Techwood	0003, 0051, 0056, 1037, 1149, 1506
Teckton	1376
Tecnimagen	1454
Teco	0003, 0030, 0036, 0051, 0053, 0068, 0092, 0093, 0178, 0218, 0264, 0280, 0474, 0180, 0653, 0755, 0779, 0282, 1523, 0835, 0466, 1578, 2114, 2180, 2300, 2674
Tecsonic	2471
Tedelex	0003, 0208, 0217, 0284, 0418, 0283, 0606, 0726, 0748, 0178, 1537, 1681, 0898, 1709
Teiron	0003
Tek	0795, 0820
Teknika	0016, 0019, 0039, 0054, 0056, 0060, 0092, 0150, 0179, 0180, 0186, 0312
TELE System	0876, 0640, 1580, 1677, 0898
Teleavia	0196, 0240, 0287, 0333, 0343, 0103, 0109, 0568
Telecor	0037, 0163, 0217, 0218, 0284, 0394
Telefunken	0005, 0037, 0056, 0073, 0074, 0101, 0109, 0196, 0213, 0262, 0287, 0335, 0343, 0346, 0471, 0486, 0498, 0560, 0568, 0587, 0625, 0706, 2051, 0712, 0714, 0753, 0754, 0819, 0820, 0765, 0896, 1326, 1504, 1536, 1046, 1580, 1365, 1626, 1149, 1681, 1703, 0748, 2102
Telefusion	0037
Telegazi	0037, 0163, 0218, 0264, 0284
Telemagic	0376
Telemeister	0037, 0320
Telesonic	0037
Telestar	0003, 0037, 1454, 2090, 2318
Teletech	0003, 0037, 0247, 0337, 0414, 0668, 1037
Teleton	0036, 0186, 0206, 0217, 0349, 0356
Televideon	0163, 0216, 0320
Teleview	0037
Televiso	0215, 0400
Temco	0294
Tempest	0003, 0264, 0455
Tennessee	0037
Tensai	0003, 0037, 0105, 0217, 0218, 0247, 0294, 0039, 0320, 0371, 0374, 0377, 0715, 1037
Tenson	0003, 0320
Tera	0030, 0031, 0092, 0149, 0466, 0474
Terra	0178, 1826
Tesla	0037, 0238, 1454, 0610, 0696, 0714, 0825, 1037, 0640, 1652
Tevion	0037, 1454, 0648, 0668, 0714, 0765, 0808, 0894,

	1037, 0640, 1248, 1104, 1289, 1298, 0835, 1046, 1580, 1149, 1771, 1787, 2023, 2032, 2090, 2373
Texet	0003, 0216, 0217, 0218, 0374
Texla	0748, 1239, 1421, 1439
ThemeScene	0887
Thes	1696, 2038, 2039, 2040, 2041, 2048, 2251, 0835, 2945
Thomas	1904
Thomson	0037, 0103, 0109, 0196, 0209, 0210, 0287, 0333, 0335, 0343, 0349, 0471, 0498, 0560, 0568, 0574, 0625, 0753, 0499, 0047, 1365, 1617
Thorn	0005, 0036, 0037, 0072, 0073, 0074, 0109, 0190, 0192, 0238, 0272, 0335, 0343, 0361, 0499, 0010, 0512, 0535, 0765
Thorn-EMI	0005
Thorn-Ferguson	0005, 0073, 0190, 0192, 0238, 0335, 0343, 0499
THTF	1626, 2092, 2090, 2874, 2877, 2878, 3041
Tiane	0093, 0150
Time	1626, 1792, 1793, 1964, 1997, 0802
Tiny	1196
Tiny Digital	0660
TiVo	1964
TMK	0056, 0177, 0178
TML	1756
TNCi	0017
Tobishi	0218, 1521
Tobo	0003, 0264, 0412, 0748
Tokai	0003, 0037, 0072, 0163, 0217, 0337, 0374, 0039, 0668, 1037
Tokaido	1037
Tokyo	0765, 0216, 0329, 0039
Tomashi	0218, 0282
Tongguang	0264, 0412
Tongtel	0587, 0748
Tonomac	0068
Tophouse	0180, 0672, 1104
Topline	0668, 1037
Toshiba	0003, 0036, 0060, 0070, 0089, 0093, 0102, 0109, 1145, 0149, 0154, 0156, 0161, 0195, 0204, 0217, 0044, 0264, 0412, 0765, 2051, 0650, 0736, 1037, 0150, 1155, 1173, 1289, 1343, 1046, 1582, 1652, 1398, 1670, 1959, 2233, 2335, 2732, 2785, 2802
Tosonic	0185
Tosumi	1770, 1506
Totevision	0039
Towada	0102, 0217, 0314, 0349
Toyoda	0003, 0264, 0371, 1709
Trakton	0217, 0264
TRANS-continents	0037, 0217, 0307, 1454, 0668, 0865, 1037, 1207, 1377, 2023, 1672
Transonic	0003, 0037, 0264, 0418, 0455, 0512, 0587, 0706, 0712, 0748, 0858, 1069, 1326, 1363, 1677, 1696, 2354
Transtec	0216
Trevi	2062
Triad	0218, 1454
Trical	0036
Trident	0217, 0516
Trio	1248, 0835
Tristar	0218, 0264
Triumph	0037, 0177, 0204, 0039, 0346, 0516, 1454
TruTech	0171, 1723, 2066
Tsoschi	0282
Tuntex	0003, 0030, 0092, 0474
TVE	2165

TVS	0463
TVTEXT 95	1454
TWF	1871
Uher	0037, 0076, 0206, 0320, 0370, 0374, 0418, 0480, 0486
Ultra	0192, 0391, 1323
Ultravox	0037, 0087, 0102, 0163, 0213, 0216, 0247, 0314, 0356, 0374
UMC	1513, 1606, 1614, 1745, 1709, 1849, 2059, 2061, 2062, 2107, 2165, 2168
Unic Line	0037, 0455, 0473
Uniden	2122
Union	0765
United	0037, 1454, 0587, 0714, 0715, 1037, 1149, 1652, 1770, 1820, 1916, 1506, 1983, 2200
Universal	0021, 0027, 0037, 0654, 0714, 1696
Universum	0003, 0010, 0011, 0039, 0036, 0037, 0070, 0074, 0076, 0105, 0109, 0146, 0170, 0177, 0195, 0213, 0217, 0247, 0264, 0294, 0295, 0337, 0346, 0348, 0349, 0361, 0362, 0370, 0411, 0418, 0421, 0473, 0474, 0480, 0072, 0512, 0535, 0544, 2051, 0631, 0668, 0808, 1037, 1149, 1437, 1901, 2174
Univox	0037, 0087, 0163, 0238, 0337
US Logic	1381
UTI Technology	2244
V2max	0865
V7 Videoseven	0880, 0889, 2051, 1376, 1666, 0755
Valor	1187
Vector Research	0030
Vendomatic	0288
Venturer	1545, 1727, 2047
Venus	1326
VEOS	1007
Vestel	0037, 0217, 0668, 1037, 1149, 1580, 2043
Vexa	0003, 0037
Vibrant	0272
Victor	0036, 0053, 0160, 0250, 0376, 0650, 0653
Video Concepts	0098
Videocon	0037, 0329, 0765, 0805, 1358, 1359, 0499, 1239, 0264, 0003, 0898, 1831, 2692
Videologic	0216, 0218
Videologique	0216, 0217, 0218
Videomac	0003
Videosat	0247
VideoSystem	0037
Videotechnic	0216, 0217, 0320, 0374
Videoton	0163, 0356, 0283
Vidikron	0054, 0376, 1398
Vidtech	0019, 0036, 0178
Viewpia	0876
Viewsonic	0724, 0797, 0857, 0864, 0885, 1365, 1511, 1513, 1542, 1564, 1578, 0755, 2258, 1745, 2014, 2087, 2111, 2280, 2281
Viking	0046, 0312
Viore	1207, 1684, 1714, 2059, 2032, 1849, 2051
Viper	0337
Visa	0203
Visart	1336, 1999
Visco	0810
Visiola	0216
Vision	0039, 0037, 0217, 0264, 0320, 0474, 0072, 0841, 1826, 2299, 2305
Vistar	0206
Vistron	1363, 2019, 2142
Visual Innovations	2059

Vitek	2295
Vito	1852, 2365, 2366, 2375, 2377, 2378
Vivax	0894, 0499, 1326, 1617, 1709, 1843, 0753, 2081
Vivid	0499, 2609
Vivo	2410
Vizio	0054, 0864, 0885, 1756, 1758, 2116, 2209, 2707
VMS	0314
Vortec	0037
Voxson	0037, 0076, 0087, 0163, 0178, 0356, 0418, 1898, 2180, 2197, 2472, 1531, 2706
VSA	0765, 1358, 1359
VU	1037, 1365, 2098, 2399, 2449
Vue	1236, 1534, 1570
Walker	1149, 1506, 2353
Wallis	0203
Waltham	0037, 0109, 0217, 0356, 0418, 0283, 0443, 0668, 1037
Wansa	2098, 3018
Wards	0000, 0016, 0017, 0018, 0019, 0020, 0021, 0024, 0027, 0028, 0029, 0030, 0047, 0051, 0054, 0056, 0060, 0080, 0096, 0135, 0154, 0156, 0165, 0166, 0178, 0179, 0180, 0186, 0187, 0866, 1347
Warumaia	0374, 0391, 0634
Watson	0003, 0037, 0163, 0203, 0213, 0218, 0320, 0394, 0464, 0654, 0668, 0714, 1037, 1376, 1437, 1504
Watt Radio	0102, 0163, 0213, 0216, 0314, 0349, 0544
Waycon	0156
Wega	0036, 0037, 0087, 0213
Wegavox	0003
Weipai	0003
Welltech	0714, 1652
Weltblick	0217, 0320
Weltstar	1037
Westinghouse	0003, 0451, 0885, 0889, 0890, 1282, 1300, 1381, 0755, 1826, 0466, 2195, 0867, 2294, 2299, 2305, 2324, 2499
Weston	1421, 1881, 1885
Wharfedale	0037, 1037, 1454, 0748, 0896, 1324, 1046, 1613, 1581, 1149, 1681, 1707, 1983, 1988, 2055, 2134, 2212
Whip	1987
White Westinghouse	0037, 0186, 0216, 0320, 0337, 0463, 0451, 1909, 2368
Wilson	1454
WinBook	1381, 0060
Winco	0412
Windsor	0668, 1037
Windstar	0282, 0337
Windy Sam	1454
Wintel	0714, 1006, 1677
World-of-Vision	0865, 0877, 0880, 0890, 0889, 1289, 1298, 1606, 1614, 2001
Worldview	0455
Wyse	1365
X-View	1191
X4-Tech	1609, 1662, 2308, 2771, 2825, 2854, 2857, 2860, 2863, 3111
XDome	0765
Xenius	0634
Xi-En	1770
Xiahua	0003, 0264, 0412, 0706, 0773, 0779, 0150
Xianghai	0003
Xiangyang	0264, 0412
Xiangyu	0003
Xihu	0264, 0412, 0150

Xinaghai	0412
Xingfu	0003
Xinghai	0264
Xinrisong	0768, 1910
Xinsida	0329
Xion	1792
Xiron	1983
XLogic	0706, 0748
XMS	1421
XO Vision	1186
Xoceco	0773, 0779, 1064, 1065, 1196, 2237, 2577, 2613, 1843, 3087
Xomax	1770
Xoro	1196, 0889, 0765, 1507, 1789, 2067, 2062, 1324, 2148, 2149, 2150
Xrypton	0037
Xuelian	0768, 1910
Xyno	2430
Yakumo	1613, 2297
Yalos	1771
Yamada	1340
Yamaha	0019, 0030, 0650, 0797, 0854, 1576
Yamishi	0037, 0217, 0218, 0282, 0455
Yapshe	0250
Yes	1375, 0898, 1696
Yingge	0003
Yokan	0037
Yoko	0003, 0037, 0216, 0217, 0218, 0247, 0264, 0305, 0208, 0370, 0421, 0283
Yongbao	0768, 1910
Yonggu	0003
Yorx	0218
Yoshita	0825
Youlanasi	0150
Yousida	0003, 0768, 1910
Ytaiwai	1531
YU-MA-TU	0037, 0796
Yuhang	0003
Zaapa	1189
Zanela	0238
Zanussi	0206, 0217, 0286, 0305, 0356
Zenith	0000, 0016, 0017, 0030, 0037, 0047, 0092, 0160, 0178, 0463, 0451, 1145, 1365, 1904, 1909, 1911, 1929, 1920
Zenor	0208
Zepto	1580
ZhuHai	0003, 0374
Ziggo	1818, 1295
Zinwell	2116, 2281, 2325
Zonda	0003, 0706, 0779