

SPV E200 Bluetooth Connections

You can use the Microsoft® Wireless Transceiver for Bluetooth® to transfer files, e-mail, and other information between your SPV E200 Smartphone and your computer. For this to work correctly, you must first configure the computer and Smartphone to communicate with each other.

This document will help you configure your computer and your Smartphone to communicate over a Bluetooth connection. This document will also step you through using Microsoft ActiveSync® over Bluetooth to synchronize your e-mail and contact information.

These instructions assume that:

- You have already set up and configured your Microsoft Wireless Transceiver for Bluetooth on your computer.
- You have installed Microsoft ActiveSync version 3.7.1 or later on your computer.
- You have configured your Smartphone to synchronize successfully with ActiveSync through the supplied device cradle or data cable.
- You are running Microsoft Windows® XP with Service Pack 2 installed.

To configure your Smartphone for Bluetooth

- 1 On your Smartphone, press **Start**, press **Settings**, and then press **Bluetooth**.
- 2 Under **Bluetooth**, select **Discoverable**, and then press **Done**.
- 3 Press **Start**, press **Configurations**, and then press **BT SerialPortSetup**.
- 4 Select the **Inbound COM Port** and **Outbound COM Port** check boxes, and then press **Done**.
- 5 On the **Info** screen that appears, press **OK**.
- 6 Disconnect the Smartphone from the universal serial bus (USB) cradle or data cable.

To add a Smartphone to a computer's Bluetooth device list

- 1 On your computer, click **Start**, click **Control Panel**, click **Printers and other Hardware**, and then click **Bluetooth Devices**.
- 2 On the **Devices** tab, click **Add**.
- 3 Click **My device is set up and ready to be found**, and then click **Next**.
- 4 Select your Smartphone from the list of available Bluetooth devices.
- 5 Enter a passkey to use while connecting to your device, and then click **Next**.
- 6 On your Smartphone, press **Yes** when asked to add the device to the list of bonded devices.
- 7 On your Smartphone, enter the passkey you created in step 5, and then press **Done**.
- 8 (Optional:) On your Smartphone, enter a custom name for the computer, and then press **Done**.
- 9 Click **Finish** to close the Add Bluetooth Device wizard.
- 10 Under **Bluetooth Devices**, click the **COM Ports** tab.
- 11 Note the COM port number marked as **Incoming** for your Smartphone. You will need this number to configure ActiveSync in the following procedure.

To configure ActiveSync on your computer to use Bluetooth

- 1 On your computer, click **Start**, point to **All Programs**, and then click **Microsoft ActiveSync**.
- 2 On the **File** menu, click **Connection Settings**.
- 3 Select the **Allow serial cable or infrared connection to this COM port** check box, and then select the COM port that you noted when you were adding your Smartphone to your computer's Bluetooth device list.
Note If the COM port list is unavailable, disconnect your Smartphone from the USB cable or cradle that connects it to the computer.
- 4 Click **OK** to apply the changes.

To configure ActiveSync on your Smartphone to use Bluetooth

- 1 On your Smartphone, press **Start**, press **More**, and then press **ActiveSync**.
- 2 Press **Menu**, press **Options**, and then press **PC Settings**.
- 3 Press **Menu**, and then press **Advanced**.
- 4 Select the **Enable PC sync using this connection type** check box, select **Bluetooth**, and then press **Done**.
- 5 Return to the ActiveSync main screen.
- 6 Press **Menu**, and then press **Setup BT ActiveSync**.
- 7 On the **BT ActiveSync Setup** screen, press **Start**.
- 8 On the **Info** screen, press **OK**. The Bluetooth Settings screen will open.
- 9 Verify that Bluetooth is **On**, and then press **Done**.
- 10 Press **Done** again to return to ActiveSync.
- 11 Press **Menu**, and then press **Connect via Bluetooth**.

When the ActiveSync process starts, you have completed setup of your Smartphone.

Troubleshooting Tips

Problems connecting ActiveSync over Bluetooth

There are several possible issues that could prevent you from creating an ActiveSync connection between your computer and your Smartphone. If you are having problems connecting, try the following troubleshooting actions:

- **Restart your computer.** This will help reinitialize the Bluetooth functionality on your computer. After your computer has restarted, try creating a Bluetooth ActiveSync connection to your computer again.
- **Try a different COM port.** When you configure your connection settings in ActiveSync to allow serial cables or infrared connections, you may have more than one choice for a COM port. In rare instances, the COM port you need to choose and the one that your device displays may not match. To test your connection, try selecting another COM port from the list in Connection Settings, and then try to create a Bluetooth ActiveSync connection again.

Other troubleshooting issues

For more information about connecting your devices or troubleshooting connection problems, see:

[Orange SPV E200 support](#)

[Windows Mobile™-based Device Help and How-to](#)

[Microsoft Help and Support](#)