

Sony-Ericsson T68i Bluetooth Connections

You can use the Microsoft® Wireless Transceiver for Bluetooth® to transfer files, contacts, and other information between your Sony-Ericsson T68i mobile phone and your computer. For this to work correctly, you must first configure the computer and mobile phone to communicate with each other.

This document will help you configure your computer and your mobile phone to communicate over a Bluetooth connection, and step you through synchronizing your data.

These instructions assume that:

- You have already set up and configured your Microsoft Wireless Transceiver for Bluetooth on your computer.
- You have the Sony-Ericsson Communication Suite CD-ROM, or you have downloaded the latest version of Communication Suite 1.5.9 from the Support area at <http://www.sonyericsson.com>.
- You are running Microsoft Windows® XP with Service Pack 2 installed.

To configure your phone for Bluetooth connections

- 1 Press **Menu**, press **Connect**, press **Bluetooth**, and then press **Options**.
- 2 Select **Operation Mode**, and then choose **Automatic**.
- 3 Press **Back** to return to Bluetooth, and then choose **Discoverable**. If you want, you can customize your phone name. The phone will be discoverable for three minutes.

To add your mobile phone to Windows as a Bluetooth device

- 1 On your computer, click **Start**, click **Control Panel**, click **Printers and other Hardware**, and then click **Bluetooth Devices**.
- 2 On the **Devices** tab, click **Add**.
- 3 Select the **My device is turned on and ready to be discovered** check box, and then click **Next**.
- 4 Select your device from the list of discovered devices, and then click **Next**.
- 5 Select a passkey to send to the mobile phone, and then click **Next**.
- 6 When your phone receives the signal, select **Add to Paired**, and then enter the passkey you created on your computer.
- 7 On the **Finish** screen of the wizard, make a note of the incoming and outgoing COM ports assigned to your phone's Bluetooth connection. You will use this information to configure your phone synchronization software in the following procedure.

To install the Communications Suite and XTNDConnect PC

The Sony-Ericsson Communications Suite is a collection of programs that your mobile phone uses to interact with your computer in various ways. XTNDConnect PC is used specifically to synchronize your e-mail client, such as Microsoft Outlook®, with the corresponding applications on your mobile phone.

- 1 On your computer, start the Communication Suite installation from the CD-ROM or by double-clicking the .exe file downloaded from the Web.
- 2 Follow the setup instructions to install the Communication Suite and XTNDConnect PC on your computer. Restart your system when prompted.
- 3 After Windows has restarted, click **Start**, click **Control Panel**, and then click **Phone Monitor Options**.
- 4 Click the **COM Ports** tab.

5 Select the COM port that you wrote down earlier, and then select **Enable**.

6 Click **OK** to save your changes.

To synchronize your e-mail content, click **Start**, point to **All Programs**, point to **XTNDConnect PC**, and then click **Synchronize Sony Ericsson phone with Outlook**.

Troubleshooting Tips

Problems synchronizing your Outlook information

When using XTNDConnect PC with your T68i mobile phone, there can be issues with synchronizing data over a Bluetooth connection. If this happens, try the following steps:

- If you receive a Device not found error message, click **Retry** to search again. You may need to try more than once to complete the connection.
- When a Bluetooth connection is established, the Phone Connection Wizard may appear. Click **Next** on each screen of the wizard to return to the synchronization process. If the wizard launches more than once, click **Cancel** to skip the wizard.
- Restart your computer and try the synchronization process again.

Other issues

For more information about connecting your devices or troubleshooting connection problems, see:

[Sony-Ericsson T68i Phone Support](#)

[Microsoft Help and Support](#)