



1111 Part No. X16-84780-03

ENGLISH

Xbox 360 Controller


Thanks for choosing the Xbox 360® Controller. It has an integrated headset jack for Xbox LIVE® play and chat (sold separately) and software-controlled adjustable vibration feedback. The Xbox 360 Controller is for use with most Microsoft® Windows® XP-based computers and with the Xbox 360 video game and entertainment system.

WARNING

Before using this product, read this manual and the Xbox 360 console manuals (if used with an Xbox 360 console) for important safety and health information. Keep all manuals for future reference. For replacement manuals, go to www.xbox.com/support.

Before using this controller with a PC running Windows, you must first install Xbox 360 Controller for Windows software available at www.windowsgaming.com.

Dispose of this product in accordance with local and national disposal regulations (if any), including those governing the recovery and recycling of waste electrical and electronic equipment (WEEE).



IMPORTANT HEALTH WARNINGS ABOUT PLAYING VIDEO GAMES

Photosensitive Seizures

A very small percentage of people may experience a seizure when exposed to certain visual images, including flashing lights or patterns that may appear in video games. Even people who have no history of seizures or epilepsy may have an undiagnosed condition that can cause these "photosensitive epileptic seizures" while watching video games.

These seizures may have a variety of symptoms, including light-headedness, altered vision, eye or face twitching, jerking or shaking of arms or legs, disorientation, confusion or momentary loss of awareness. Seizures may also cause loss of consciousness or convulsions that can lead to injury from falling down or striking nearby objects.

Stop playing immediately and consult a doctor if you experience any of these symptoms. Parents should watch for or ask their children about the above symptoms—children and teenagers are more likely than adults to experience these seizures. The risk of photosensitive epileptic seizures may be reduced by taking the following precautions:

- Sit farther from the TV screen.
- Use a smaller TV screen.
- Play in a well-lit room.
- Do not play when you are drowsy or tired.

If you or any of your relatives have a history of seizures or epilepsy, consult a doctor before playing.

Musculoskeletal Disorders

Use of game controllers, keyboards, mice, or other electronic input devices may be linked to serious injuries or disorders.

When playing video games, as with many activities, you may experience occasional discomfort in your hands, arms, shoulders, neck or other parts of your body. However, if you experience symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensation, or stiffness, DO NOT IGNORE THESE WARNING SIGNS. PROMPTLY SEE A QUALIFIED HEALTH PROFESSIONAL, even if symptoms occur when you are not playing a video game. Symptoms such as these can be associated with painful and sometimes permanently disabling injuries or disorders of the nerves, muscles, tendons, blood vessels, and other parts of the body. These musculoskeletal disorders (MSDs) include carpal tunnel syndrome, tendonitis, tenosynovitis, vibration syndromes, and other conditions.

While researchers are not yet able to answer many questions about MSDs, there is general agreement that many factors may be linked to their occurrence, including medical and physical conditions, stress and how one copes with it, overall health, and how a person positions and uses their body during work and other activities (including playing a video game). Some studies suggest that the amount of time a person performs an activity may also be a factor.

Some guidelines that may help you work and play more comfortably and possibly reduce your risk of experiencing an MSD can be found in the Healthy Gaming Guide at www.xbox.com. These guidelines address topics such as:

- Positioning yourself to use comfortable, not awkward postures.
- Keeping your hands, fingers and other body parts relaxed.
- Taking breaks.
- Developing a healthy lifestyle.

If you have questions about how your own lifestyle, activities, or medical or physical condition may be related to MSDs, see a qualified health professional.

SET UP YOUR XBOX 360 CONTROLLER

Connect Your Controller to Your Console

To connect your Xbox 360 Controller to your console, insert the controller cord connector into either controller port on the front of the console. To disconnect, pull the controller cord connector out. Be sure to pull on the connector, not the cable.

NOTE

Do not touch controller cord terminals with your fingers or allow metal parts to touch them. Doing so may damage the controller or the console.

中文

Xbox 360 控制器

感謝您購買 Xbox 360® 控制器。它整合了耳機接頭，可讓您在 Xbox LIVE® 上進行遊戲與交談，還提供了可使用軟體調整的震動功能。

Xbox 360 控制器可在大多數安裝 Microsoft® Windows® XP 的電腦與 Xbox 360 視訊遊戲家庭娛樂系統上使用。

警告

在使用此產品前，請閱讀本手冊與 Xbox 360 手冊 (如果與 Xbox 360 主機搭配使用)，以取得重要的安全和健康資訊。請妥善保存所有手冊，以供未來參考之用。如需下載手冊，請至 www.xbox.com/support。

在執行 Windows 的個人電腦上使用此控制器前，您必須先安裝「Windows 專用 Xbox 360 控制器」軟體，下載網址為：www.windowsgaming.com。

亞太國家/地區專用 (澳大利亞除外)

有限瑕疵擔保網址 www.xbox.com/warranty

本產品的廢棄處理需依照當地和全國廢棄物處理規定 (如果適用)，包括管理廢棄電子電機設備 (WEEE) 的再生與回收的相關規定。



進行視訊遊戲的重要健康警告

光刺激誘發癲癇症

有極少數的人在觀看一些視覺影像時可能會突然癲癇發作，這些影像包括電玩遊戲中出現的閃光或圖形。甚且連沒有突然發病或癲癇史者也可能在進行電玩遊戲時，出現類似癲癇症狀，這類未經診斷的症狀稱為「光刺激誘發癲癇症」。

癲癇症狀包括頭昏眼花、視幻覺、眼部或臉部抽搐、手腳痙攣、暫失方向感、精神混淆或者暫時失去意識。癲癇發作時可能因為失去意識或抽筋之故，跌落地面而受傷或碰撞到周遭物品。

若出現以上所述任何症狀，請立即停止該遊戲並送醫診斷。家長應該在場看顧或者詢問您的兒女是否有以上症狀，相較於成人，兒童及青少年更有可能發生此類癲癇症。為降低誘發光刺激癲癇的發生，可進行下列預防措施：

- 坐在距離電視螢幕較遠的地方。
- 使用較小的電視螢幕。
- 在照明充足的室內進行遊戲。
- 不要在疲累或倦怠時進行遊戲。

如果您自己或您的親友有癲癇史，請在進行遊戲之前先與醫師諮詢。

NOTE

Clean only with a dry or slightly damp cloth. Using cleaning solutions or attempting to clean connectors may damage your controller.

Turn Your Console On and Off

To turn on your Xbox 360 console using the controller, press **Start** or the Xbox Guide button.

To turn off your console using the controller, press and hold the Xbox Guide button for three seconds and then confirm that you want to turn it off.

You can also turn the console on and off by pressing the power button on the front of the console.

Connect Your Controller to a PC

Xbox 360 Controller software for Windows enables the Xbox 360 Controller to work with a PC running Windows XP. To download the software, go to www.windowsgaming.com. You must first install the software, then connect the Xbox 360 Controller to your computer's USB port.

After installing the Xbox 360 Controller for Windows software and connecting your controller to your computer's USB port, you can verify that the controller is working by selecting Game Controllers from the Windows Controller panel. See your game manual to determine whether your specific game works with the Xbox 360 Controller.

The Xbox 360 Controller for Windows HELP contains the following important product information:

- End-User License Agreement (EULA) and Warranty.

USING YOUR CONTROLLER

Xbox Guide Button

Your controller is equipped with a button in its centre called the Xbox Guide button. Press the Xbox Guide button to turn on your console or to go to the Xbox Guide if the console is already on. See your Xbox 360 Setup manual for more details about the Xbox Guide button.

NOTE

The Xbox Guide button has no function when using the Xbox 360 Controller with a Windows-based PC.

Ring of Light

The Xbox Guide button is surrounded by the Ring of Light, which is made up of four quadrants. When you connect the controller to an Xbox 360 console or play a game using the controller on your computer, the quadrant indicating your position or player number glows.

Expansion Port

The expansion port on your controller connects to devices such as the Xbox 360 Headset (sold separately). The port features a 2.5mm audio connector and other connectors for additional devices. For more information, see the instruction manual for your headset or other device.

Hearing Loss

Extended exposure to high volumes when using a headset may result in temporary or permanent hearing loss. Some unapproved third-party headsets may produce higher sound levels than approved Xbox 360 Headsets.

The Inline Release

Your controller cord has an inline release. This is a safety feature designed to reduce the chance of the Xbox 360 console or a computer falling when the cord is pulled. If the console or a computer falls and hits someone, especially a small child, it could cause serious injury. To reduce the risk of injuries or damage to the console or a computer, it is important to use the controller and the inline release properly. Use the controller connector, not the inline release, to routinely connect and disconnect the controller. If an inline release disconnects, simply reconnect it by aligning the grooved indentations and pressing the two parts completely together. The controller will not work unless the inline release is connected properly.

Never tape, glue or otherwise prevent an inline release from pulling apart.

The inline release reduces, but does not eliminate, the risk of the console or a computer being pulled off its surface. To further reduce the risk:

- Do not allow anyone to pull on the controller or controller cord in a way that causes the console or a computer to move.
- Do not allow controller cords to become crossed or tangled with one another.

IF YOU NEED MORE HELP

For answers to common questions, troubleshooting steps, and Xbox Customer Support contact information, visit www.xbox.com/support.

Do not take your Xbox 360 console or its accessories to your retailer for repair. Please visit www.xbox.com/support for troubleshooting and service information.

Do Not Attempt Repairs

Do not attempt to take apart, service or modify the Xbox 360 console, power supply or its accessories in any way. Doing so could present the risk of serious injury or death from electric shock or fire, and for safety reasons it will void your Express Warranty.

COPYRIGHT

Information in this document, including URL and other Internet Web site references, is subject to change without notice. Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of Microsoft Corporation. Microsoft may have patents, patent applications, trademarks, copyrights or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written licence agreement from Microsoft, the furnishing of this document does not give you any licence to these patents, trademarks, copyrights or other intellectual property.

© 2011 Microsoft Corporation. All rights reserved.

Microsoft, Xbox, Xbox 360, Xbox LIVE, the Xbox logos, and the Xbox LIVE logo are trademarks of the Microsoft group of companies.

肌肉骨骼失調病症

使用遊戲控制器、鍵盤、滑鼠、或其他電子輸入裝置都可能會導致嚴重的傷害或疾病。正如從事許多其他活動一樣，在使用電腦時，您的手掌、手臂、肩膀、頸部或身體的其他部分，都有可能感到間歇性的生理不適。但是，您若有長期或重複性的生理不適、疼痛、顫抖、刺痛、麻痺、燒熱感或僵硬等症狀，切勿忽略這些警訊。應立即向合格的醫療專業人員尋求治療，即使症狀並非在您進行視訊遊戲期間出現，也不應忽視。這些症狀可能會伴隨疼痛，有時神經、肌肉、肌腱或身體其他部位可能也會出現永久性的失能傷害或不舒適。這些肌肉骨骼失調疾病 (MSD) 包括手腕道綜合病徵、肌腱炎、韌鞘炎和其他疾病等。

雖然目前研究人員尚未能解答許多有關肌肉骨骼失調的問題，但一致認為與許多因素有關，包括：整體健康情況、壓力與個人調適方式、醫療生理狀況，以及在工作或從事其他活動 (包括進行視訊遊戲) 期間，個人調整與使用其身體的方式。從事某項工作的時間長短可能也是需要考慮的因素。

您可以在本《健康遊戲指南》(可在 www.xbox.com 上取得) 找到說明指示，協助您更舒適地工作或玩遊戲，同時減少罹患肌肉骨骼失調的機率。這些指導方針主題包括：

- 讓身體保持舒服的姿勢進行遊戲。
- 持續放鬆您的手部、手指與其他身體部位。
- 適時休息。
- 發展健康的生活方式。

若您對自己的生活型態、活動、醫療、生理狀況，與肌肉骨骼失調的關聯性有任何疑問，請諮詢合格的醫療專業人員。

安裝您的 XBOX 360 控制器

將控制器連接到主機

如要將 Xbox 360 控制器連接到 Xbox 360 主機，請將控制器纜線接頭連接到主機正面的控制器連接埠。如要中斷連接，請移除控制器，但請確認您是以拔除接頭的方式，而非以拉扯纜線的方式來移除控制器。

注意

請避免直接用手指或金屬物品觸碰控制器纜線終端，這麼做可能會傷害到控制器或主機。僅可使用乾布或微濕的布清理。使用清潔劑或試圖清理接頭有可能會損壞您的控制器。

開啟或關閉主機

如要使用控制器開啟 Xbox 360 主機電源，請按下 START 鍵或 Xbox 360 按鍵。

如要使用控制器關閉 Xbox 360 主機電源，請按住 Xbox 360 按鍵 3 秒鐘，然後確認關閉主機電源。您也可以按下主機正面的電源開關來開啟或關閉主機。

將控制器連接到個人電腦

「Windows 專用 Xbox 360 控制器」軟體可讓您在執行 Windows XP 的個人電腦上使用 Xbox 360 控制器。如要下載軟體，請前往 www.windowsgaming.com。您必須先安裝軟體，才能將 Xbox 360 控制器連接到電腦上的 USB 連接埠。

當您安裝好「Windows 專用 Xbox 360 控制器」軟體，並將控制器連接到電腦上的 USB 連接埠後，即可在 [Windows 控制器] 面板上按一下 [遊戲控制器]，來確認控制器是否運作正常。

「Windows 專用 Xbox 360 控制器」軟體的說明檔包含下列重要的產品資訊：

- 使用者授權合約 (EULA) 及有限瑕疵責任擔保。

使用控制器

Xbox 360 按鍵

控制器中央的按鍵稱為「Xbox 360 按鍵」，您只要按下 Xbox 360 按鍵即可開啟主機電源。如果主機已經開啟，按下 Xbox 360 按鍵即可進入快顯功能表。如需 Xbox 360 按鍵的詳細資訊，請參閱 Xbox 360 設定手冊。

注意

在 Windows 個人電腦上使用 Xbox 360 控制器時，Xbox 360 按鍵不具任何作用。

光環

Xbox 360 按鍵四周有光環圍繞，這光環是由 4 個控制器指示所組成。當您將控制器連接到 Xbox 360 主機，或在電腦上使用控制器時，代表您位置或玩家編號的控制器指示將會亮起。

擴充座

控制器上的擴充座可用來連接其他裝置，例如 Xbox 360 耳機（需另購）。擴充座配有一個 2.5mm 的音效接頭，以及可供額外裝置使用的其他接頭。如需詳細資訊，請參閱您耳機或其他裝置的操作手冊。

⚠ 聽力受損

若持續在高音量下使用耳機，可能會導致您的聽力暫時或永久受損。某些未原廠授權的協力廠商耳機可能比原廠授權的 Xbox 360 耳機產生更高的音量。

⚠ 同軸鬆脫裝置

您的控制器纜線都有同軸鬆脫裝置。這個特別的安全設計是用來減少 Xbox 360 主機或電腦因拉扯纜線而掉落的機率。如果主機或電腦掉落並打中人，尤其是小孩，將會造成嚴重的傷害。為減低受到這類傷害的風險，以及造成主機或電腦受損或毀壞，請小心使用控制器與同軸鬆脫裝置。但平常還是使用控制器接頭來連接或中斷連接，勿採用同軸鬆脫裝置。如果同軸鬆脫裝置的連接中斷，則只要對準凹口並將兩頭按緊便可回復連接。除非同軸鬆脫裝置已連接妥當，否則控制器不會正常運作。

切勿使用膠帶、膠水或其他黏著劑等將同軸鬆脫裝置粘牢。

同軸鬆脫裝置可以減少但無法完全消除電腦或主機掉落的風險。若要大幅降低風險：

- 勿允許任何人拉扯控制器或控制器纜線，以避免主機或電腦移動。
- 請將控制器的電線整理好，切勿糾纏在一起。

한국어

Xbox 360 컨트롤러

Xbox 360® 컨트롤러를 구입해 주셔서 감사합니다. Xbox LIVE®에서 게임을 즐기면서 채팅을 할 수 있는 헤드셋 잭이 있고 포스 피드백 기능도 제공합니다.

Xbox 360 컨트롤러는 Microsoft® Windows® XP가 설치되어 있는 대부분의 컴퓨터와 Xbox 360 비디오 게임 및 엔터테인먼트 시스템에서 사용할 수 있도록 제작되었습니다.

⚠ 경고

제품을 사용하기 전에 이 설명서 및 Xbox 360 사용 설명서 (Xbox 360 본체와 함께 사용되는 경우)에 명시된 안전을 위한 주의 사항을 읽으십시오. 모든 설명서는 나중에 참고할 수 있도록 보관하십시오. 설명서를 분실한 경우 www.xbox.com/support를 방문하십시오.

⚠ 이 기호는 이 설명서에 있는 안전을 위한 주의 사항을 나타냅니다. Windows가 설치되어 있는 PC에서 이 컨트롤러를 사용하려면 우선 www.windowsgaming.com에서 Xbox 360 Controller for Windows 소프트웨어를 다운로드하여 설치해야 합니다.

전기 및 전자 장비 폐기물(WEEE)의 재활용을 관할하는 규정을 비롯하여 지역 및 국가의 폐기물 처리 규정(해당되는 경우)에 따라 이 제품을 폐기하십시오.

⚠ 비디오 게임 플레이에 대한 안전을 위한 주의 사항

광과민성 반응

극소수의 사람들은 비디오 게임 등에서 볼 수 있는 번쩍이는 빛이나 무늬 같은 시각적 이미지에 노출될 경우 발작을 일으킬 수 있습니다. 발작 증세가 간질 병력이 없던 사람도 비디오 게임을 하는 동안 알 수 없는 원인으로 이러한 "광과민성 간질 발작"을 일으킬 수 있습니다.

광과민성 간질 발작은 현기증, 환각, 눈이나 얼굴의 경련, 팔이나 다리의 경련이나 떨림, 방향 감각 상실, 정신 착란, 일시적인 의식 상실 등과 같은 여러 가지 증상으로 나타날 수 있습니다. 발작으로 인한 의식 상실이나 경련으로 쓰러지거나 가까운 물체에 부딪혀서 다칠 수도 있습니다.

이런 증상 중 한 가지라도 경험하게 되면 즉시 게임을 중단하고 의사와 상의하십시오. 어린이와 청소년은 어른에 비해 이러한 발작을 일으키기 쉬우므로 부모님께서 자녀가 이러한 증상을 보이지 않나 살펴보고 자녀에게 위와 같은 증상이 나타난 적이 있는지 확인하셔야 합니다. 광과민성 간질 발작의 위험을 줄이려면 다음 예방 조치를 취합니다.

- TV 화면에서 멀리 떨어져 앉습니다.
- 화면이 작은 TV를 사용합니다.
- 조명이 밝은 곳에서 게임을 합니다.
- 나른하고 피곤할 때는 게임을 하지 않습니다.

본인은 물론 친척 중에서 발작 또는 간질 병력이 있는 사람이 있다면 게임을 하기 전에 의사와 상의하십시오.

근골격 장애

게임 컨트롤러, 키보드, 마우스 또는 기타 전자 입력 장치의 사용은 심각한 부상이나 장애로 이어질 수 있습니다.

조작 활동이 많은 비디오 게임을 할 경우 가꿈 손, 팔, 어깨, 목 또는 다른 신체 부위가 불편하게 느껴지는 경우는 있을 수 있습니다. 그러나 불편함, 통증, 두근거림, 결림, 마비, 작열감 또는 신체 경직 증상 등이 지속적이거나 반복적으로 느껴지면 이러한 경고 신호를 절대 간과하지 마십시오. 비디오 게임을 하지 않는 동안에도 증상이 발생하면 믿을 수 있는 전문의에게 즉시 문의하십시오. 이와 같은 증상은 통증으로 이어지며 때로는 영구적으로 신경, 근육, 힘줄, 혈관 및 다른 신체 부위의 부상이나 장애로 연결될 수 있습니다. 근골격 장애(MSD)에는 카탈 터널 증후군, 건염, 건초염, 진동 증후군 및 기타 증상이 포함됩니다.

연구자들도 아직 MSD에 대한 많은 질문에 답을 줄 수는 없지만 의학적 및 신체 상태, 스트레스와 이에 대처하는 방법, 전체적인 건강 상태, 작업 및 다른 활동(비디오 게임 플레이)의 자세와 신체를 사용하는 방법 등으로 인해 많은 요인이 발생할 수 있다는 것에는 일반적으로 동의합니다. 일부 연구에서는 개인의 작업 수행 시간에 한 요인이 될 수 있다고 주장합니다. 보다 편안하게 작업하고 게임을 즐기며 MSD의 위험을 줄일 수 있는 데 도움이 되는 몇 가지 지침은 www.xbox.com에 있는 Healthy Gaming Guide(건강한 게임을 위한 가이드)에서 찾아볼 수 있습니다. 이 지침에서는 다음과 같은 항목을 설명합니다.

- 편안하고 힘들지 않은 자세를 취합니다.
- 손, 손가락 및 다른 신체 부위의 긴장을 풁니다.
- 휴식을 취합니다.
- 건강한 생활 습관을 키워갑니다.

생활 습관, 활동, 의학적 또는 신체 상태와 MSD와의 연관성에 대한 사항은 믿을 수 있는 전문의에게 문의하십시오.

XBOX 360 컨트롤러 설치

본체에 컨트롤러 연결

본체에 Xbox 360 컨트롤러를 연결하려면 컨트롤러 코드 커넥터를 본체 앞쪽의 컨트롤러 포트 중 하나에 삽입합니다. 연결을 끊으려면 컨트롤러 코드 커넥터를 뽑습니다. 반드시 케이블이 아닌 커넥터를 잡고 뽑아야 합니다.

참고

컨트롤러 접속 부분에 손가락이나 금속 부품이 닿지 않게 하십시오. 컨트롤러나 본체가 손상될 수 있습니다.

참고

마른 천이나 약간 물기 있는 천으로만 닦습니다. 세정액을 사용하거나 커넥터를 닦으면 컨트롤러가 손상될 수도 있습니다.

본체 켜기 및 끄기

컨트롤러를 사용하여 Xbox 360 본체를 켜려면 START 단추 또는 Xbox 가이드 단추를 누릅니다. 컨트롤러를 사용하여 본체를 끄려면 Xbox 가이드 단추를 3초 동안 누른 다음 본체를 곧 짚든지 묻는 메시지를 확인합니다.

본체 앞쪽의 전원 단추를 눌러 본체를 켜고 끌 수도 있습니다.

如果您需要更多幫助

如需一般問題的解答、疑難排解步驟以及 Xbox 客戶支援部門連絡資訊，請前往 www.xbox.com/support。

請勿將您的 Xbox 360 主機或其周邊配備拿到經銷商處要求維修，請至 www.xbox.com/support 參閱疑難排解與服務資訊。

⚠ 請勿嘗試自行維修

請勿嘗試拆解、維修或修改 Xbox 360 主機、電源供應器或其周邊配備。這麼做可能會產生電擊或火苗而導致嚴重傷害或死亡，而您的保固也將無效。

台灣地區的客戶本產品資訊

產品名稱：Xbox 360 控制器

型號：Xbox 360 Controller

額定電壓：5 VDC

總額定消耗電功率或額定輸入電流：400 mA

製造年份：2010

產地：中國

製造號碼：Xbox 360 Controller

製造廠商：Microsoft Corporation

進口廠商：聯強國際股份有限公司

地址：台北市 104 民生東路二段 75 號四樓

洽詢專線：(02) 2506-3320

著作權

本文件中的資訊 (包括 URL 及其他網際網路網站參考資料) 如有變更，恕不另行通知。基於 (但不限於) 著作權法下之權利，未經 Microsoft Corporation 明示書面許可，貴用戶不得為任何目的使用任何形式或方法 (電子形式、機械形式、影印、記錄或其他方法) 複製、儲存或傳送本文件的任何部分或將本文件任何部分放入檢索系統 (retrieval system)。

Microsoft 可能就本文件所提及內容及文件標的擁有專利權、專利申請權、商標權、著作權、或其他智慧財產權。除非 Microsoft 書面授權合約所明示規定者外，提供本文件並不授予貴用戶上述專利權、商標權、著作權或其他智慧財產權。

© 2011 Microsoft Corporation. 著作權所有，並保留一切權利。

Microsoft、Xbox、Xbox 360、Xbox LIVE、Xbox 標誌及 Xbox LIVE 標誌係 Microsoft 集團的商標。

PC에 컨트롤러 연결

Xbox 360 Controller for Windows 소프트웨어를 설치하면 Windows XP가 설치되어 있는 PC에서 Xbox 360 컨트롤러를 사용할 수 있습니다. 소프트웨어를 다운로드하려면 www.windowsgaming.com을 방문하십시오. 소프트웨어를 설치한 다음 컴퓨터의 USB 포트에 Xbox 360 컨트롤러를 연결해야 합니다.

Xbox 360 Controller for Windows 소프트웨어를 설치하고 컴퓨터의 USB 포트에 이 컨트롤러를 연결한 후 Windows의 제어판에서 게임 컨트롤러를 선택하면 컨트롤러의 작동 상태를 확인할 수 있습니다. 특정 게임에서 Xbox 360 컨트롤러를 지원하는지 여부를 확인하려면 게임 설명서를 참고하십시오.

Xbox 360 Controller for Windows 도움말에는 다음과 같은 중요한 제품 정보가 나와 있습니다.

- 최종 사용자 사용권 계약(EULA) 및 제한적 보증

컨트롤러 사용

Xbox 가이드 단추

컨트롤러 중앙에는 Xbox 가이드 단추가 있습니다. Xbox 가이드 단추를 눌러 본체를 켜거나 본체가 이미 켜져 있는 경우 Xbox 가이드로 이동합니다. Xbox 가이드 단추에 대한 자세한 내용은 Xbox 360 사용 설명서를 참고하십시오.

참고

Windows 기반의 PC에서 Xbox 360 컨트롤러를 사용하는 경우 Xbox 가이드 단추는 작동하지 않습니다.

표시등

Xbox 가이드 단추는 4방향의 표시등으로 둘러싸여 있습니다. 컨트롤러를 Xbox 360 본체에 연결하거나 컴퓨터에서 컨트롤러를 사용하여 게임을 하는 경우 컨트롤러 포트 번호나 플레이어 번호에 해당하는 표시등에 불이 들어옵니다.

확장 포트

Xbox 360 헤드셋(별도 구입) 등의 장치를 컨트롤러 확장 포트에 연결할 수 있습니다. 이 포트에는 2.5mm 오디오 커넥터 및 기타 다른 장치의 커넥터도 연결할 수 있습니다. 자세한 내용은 헤드셋 또는 기타 장치의 제품 설명서를 참고하십시오.

⚠ 청력 상실

오랫동안 헤드셋의 볼륨을 높여서 사용할 경우 일시적이거나 영구적으로 청력을 상실할 수 있습니다. 승인되지 않은 타사 헤드셋 중 일부는 승인된 Xbox 360 헤드셋보다 더 큰 소리가 날 수 있습니다.

⚠ 인라인 릴리스

컨트롤러 코드에는 인라인 릴리스가 있습니다. 이것은 코드를 뽑을 때 Xbox 360 본체 또는 컴퓨터가 넘어질 가능성을 줄이기 위해 고안된 안전 기능입니다. 본체 또는 컴퓨터가 넘어져서 사람, 특히 어린이에게 타격이 가해지면 심각한 상해를 입을 수 있습니다. 컴퓨터나 본체에 가해지는 파손 또는 손상을 줄이려면 컨트롤러와 인라인 릴리스를 적절하게 사용하는 것이 중요합니다. 일상 생활에서는 인라인 릴리스가 아닌 컨트롤러 커넥터를 사용하여 컨트롤러를 연결하거나 분리하는 것이 좋습니다. 인라인 릴리스가 분리된 경우, 움푹하게 홈이 패인 곳을 맞추어 두 부분이 완전히 맞도록 누르면 컨트롤러를 간편하게 다시 연결할 수 있습니다. 인라인 릴리스가 제대로 연결되어 있지 않으면 컨트롤러가 작동하지 않습니다.

인라인 릴리스가 분리될 때 문제가 발생할 수 있으니 테이프나 접착제 등은 사용하지 마십시오.

인라인 릴리스가 사용한다고 하더라도 본체나 컴퓨터가 떨어지는 위험을 완전히 없애지는 못하지만 줄일 수는 있습니다. 위험을 좀 더 줄이려면 다음을 주의하십시오.

- 본체나 컴퓨터가 움직이지 않게 하려면 컨트롤러나 컨트롤러 코드를 잡아 당기지 말아야 합니다.
- 컨트롤러 코드가 다른 장치와 교차되거나 꼬이지 않게 하십시오.

도움이 더 필요한 경우

일반적인 질문에 대한 답변, 문제 해결 절차 및 Xbox 고객 지원 센터 연락처 정보를 확인하려면 www.xbox.com/support를 방문하십시오.

수리 및 서비스를 받기 위해 Xbox 360 본체나 해당 액세서리를 판매점에 직접 가져가지 마십시오. 문제 해결 및 서비스 정보를 확인하려면 www.xbox.com/support를 방문하십시오.

⚠ 절대 직접 수리하려고 하지 마십시오.

Xbox 360 본체, 전원 공급 장치 또는 액세서리를 직접 분해, 수리 또는 개조하지 마십시오. 감전이나 화재로 심각한 상해를 입거나 목숨을 잃을 수 있으며 보안상의 이유로 보증도 무효가 됩니다.

이 기기는 가정용(B급)으로 전자파적합등록을 한 기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

저작권

URL 및 기타 인터넷 웹 사이트 참조를 포함한 이 설명서의 내용은 예고 없이 변경될 수 있습니다. 해당 저작권법을 준수하는 것은 사용자의 책임입니다. 저작권에서의 권리와는 별도로, 이 설명서의 어떠한 부분도 Microsoft의 명시적인 서면 승인 없이는 어떠한 형식이나 수단(전자적, 기계적, 복사)에 의한 복사, 디스크 복사 또는 다른 방법) 또는 목적으로도 복제되거나, 검색 시스템에 저장 또는 도입되거나, 전송될 수 없습니다.

Microsoft는 이 설명서 주요 내용에 관련된 특허권, 상표권, 저작권, 또는 기타 지적 재산권 등을 보유할 수 있습니다. 서면 라이선스 계약에 따라 Microsoft로부터 귀하에게 명시적으로 제공된 권리 이외에, 이 설명서의 제공은 귀하에게 이러한 특허권, 특허출원, 상표권, 저작권, 또는 기타 지적 재산권 등에 대한 어떠한 사용권도 허여하지 않습니다.

© 2011 Microsoft Corporation. All rights reserved.

Microsoft, Xbox, Xbox 360, Xbox LIVE, Xbox 로고 및 Xbox LIVE 로고는 Microsoft 그룹 계열사의 상표입니다.